


Trimble 3300DR

User Guide



Topo Software
PN 571 703 151

Contents

1 Introduction	Dear Customer	1-2
	The System Philosophy	1-3
	Important Notes	1-4
2 Trimble® 3300DR - the Routine Total Stations	Instrument Description	
	Hardware Overview.....	2-2
	The Routine Total Stations Trimble 3300DR.....	2-3
	DR Measurement Direct Reflex mode and Laser Pointer	2-4
	Program Versions	
	Overview about software version “Topo”	2-5
	Overview about software version “Construct.” ..	2-6
	Operation	
	Overview about software “Topo”	2-7
	The Keyboard	2-9
	Using the different EDM Modes DR/PR and Laser Pointer	2-10
	Direct Reflex Distance Measurement.....	2-12
	The Basic Concept of the Menu.....	2-15
	Use of this Manual	2-16
	Safety Notes	
	Risks in Use	2-17
	Laser Beam Safety	2-20
	Laser Beam Safety DR - EDM in Direct Reflex Mode Laser Pointer	2-20
	Laser Beam Safety DR – EDM in Prism Mode ..	2-21
	Labelling	2-22
	From Power to Data	
	Overview.....	2-23

3 First Steps

Before Measurement

Set-Up and Coarse Centring	3-2
Levelling and Fine Centring.....	3-2
Telescope Focusing	3-4
Switching the Instrument on	3-5

Principles

Principles of Display.....	3-6
Principles of Input	3-7
Input of Reflector, Trunnion Axis and Station Heights	3-8
Heightstationing: Input of t_h and i_h/Z_s	3-9
Measurement "Stationing in Elevation"	3-10
Input of Point Number and Point Code	3-11
Principles of Distance Measurements.....	3-12
Distance tracking (continuous measurement of the distance)	3-12
Measurements to inaccessible Points	3-13

Presettings

Introduction.....	3-14
Settings in the Set-Up Menu	3-15
Frequently used Settings	3-18
Rarely used Settings	3-19
Recording the Measurement	3-26
Recording default values (Header) and changed settings.....	3-27

Measurement in the Start-Up Menu

Selecting the Measuring Mode (presentation of the results at the display)	3-28
Measurement.....	3-30

4 Coordinates

The Menu Guidance

Principle	4-2
Station Point Memory	4-4
Trimble 3303DR / 3305DR	
Special Features of Trimble 3306DR	4-4

Unknown Station

Stationing in Elevation.....	4-6
Measurement „Unknown Station“	4-7
Recording	4-10

Known Station

Measurement „Known Station“	4-11
Orientation using a known Azimuth.....	4-12
Orientation using known Coordinates	4-13
Recording	4-14

Stationing in Elevation

Measurement „Stationing in Elevation“	4-15
Recording	4-17

Polar/Detail Points

Confirmation of Stationing.....	4-18
Measurement „Polar/Detail Points“	4-20
Eccentric Measurement	4-21
Intersection	4-22
DR-Menu	4-25
Recording	4-28

Stake Out

Confirmation of Stationing.....	4-29
Measurement „Stake Out“	4-31
Stake Out using known nominal Parameters ..	4-31
Stake Out using known Stake Out Parameters	4-32
Measurement Results	4-33
Recording	4-34

5 Applications

The Menu Guidance

Principle 5-2

Connecting Distance

Measurement „Connecting Distance“ 5-5

Polygonal Connecting Distance 5-7

Radial Connecting Distance 5-8

Recording 5-9

Object Height + Width

Measurement „Object Height“ 5-10

Definition of a Reference Height ZSet 5-11

Measurement beside the Plumb Line 5-12

Recording 5-13

Station + Offset

Measurement „Station + Offset“ 5-14

The Station equals Point A $A=S$ 5-18

The Station equals Point B $B=S$ 5-19

The Station equals Point P $P=S$ 5-19

Shifting the Coordinate Axes y,x 5-20

Recording 5-22

Vertical Plane

Measurement „Vertical Plane“ 5-23

hSet - Determination of the

Height Coordinate 5-24

xSet - Definition of the x-Axis 5-25

ySet - Points in front or behind the Plane 5-26

The Station equals Point P $P=S$ 5-27

Recording 5-27

Area Calculation

Measurement „Area Calculation“ 5-28

Recording 5-31

6 Data Management

Editor

Calling the EDIT Menu.....	6-2
Display of Data Lines	6-2
Searching for Data Lines.....	6-3
Deleting Data Lines	6-4
Entering Data Lines	6-6

Data Transfer

Introduction.....	6-8
Preparation on the Instrument	6-9
Preparation on the PC – Hyperterminal Settings.....	6-10
Data Transmission.....	6-13
Data Reception.....	6-14

Data Formats

Introduction.....	6-15
Description of M5 data format.....	6-16
Additional data lines of M5 data format - Header/changed settings	6-19
Description of Rec 500 data format.....	6-24
Description of R4 and R5 (M5, Rec 500) format of Trimble 3300DR	6-26
Defination of type identification	6-32
Type identifier-CZ Formats M5, R4, R5, Rec500 (Trimble 3300DR)	6-32
Description of value blocks	6-35
Trimble/Elta® Format ID and address block.....	6-36
Data output on a printer	6-37

User Interface

Introduction.....	6-38
What is an interface?	6-38
Hardware interface.....	6-39

Remote Control

Introduction.....	6-40
Xon/Xoff Control.....	6-40
Rec 500 Software Dialog (Rec 500 Protocol).....	6-40
Key Codes and Function Requests	6-42
Examples for the parameter calls	6-45
Trimble 3300DR controlled from Map500 or TSC1/TSCe.....	6-48

Recording Data Lines
Recording Data Lines..... 6-63

Update
Introduction..... 6-70
Preparation on the Instrument 6-71
Preparation on the PC 6-74
Starting Update..... 6-76

Contents

7 Adjusting and Checking	Introduction	7-2
	V Index / Hz Collimation	7-4
	Compensator	7-6
	DR EDM System – Laser Beam	
	The DR EDM System.....	7-7
	Inspection of the Laser Beam Direction	7-7
	Adjusting the Laser Beam Direction	7-8
8 Annex	Overview Softkeys	8-2
	Overview Key Functions	8-6
	Geodetic Glossary	8-7
	Technical Data	
	Trimble 3303DR, 3305DR and 3306DR.....	8-14
	Electromagnetic Compatibility (EMV)	8-18
	Single Battery Charger	8-19
	Charging the Battery	8-21
	Formulae and Constants	
	Computational Formulae for	
	Angle Measurements	8-23
	Computational Formulae for	
	Distance Measurements	8-23
	Reduction Formulae	8-24
	Verifying on Calibration Distances	8-26
	Prism and Addition Constants	8-27
	Error Messages	
	Error Message What to do?.....	8-28
	Before you call the service	8-30
	Maintenance and Care	
	Instructions for Maintenance and Care.....	8-31
	Transport Case	
	Keeping the Measurement System	
	in the Case.....	8-32
	Trimble 3303 /3305 x-treme	
	Trimble 3303 / 3305 x-treme	
	Extended Temperature Range	8-33

Dear Customer 1-2

The System Philosophy 1-3

Important Notes 1-4

Dear Customer

By purchasing a Trimble® 3300DR Routine Total Station from Trimble you have opted for a leading-edge product in the field of surveying instruments. We congratulate you on your choice and would like to thank you for the trust placed in our company.

For quite some time, surveying has no longer been limited to the measurement of bearings and distances. Complex measurement systems have been in demand that do not only satisfy ever increasing needs for automatization, but also those involving digital data processing as well as the effectiveness of daily measuring practice. New standards have thus been set regarding technology and operating convenience.

The Trimble 3300DR Routine Total Station is part of a complete range of surveying instruments from Trimble. Data interchange between all the instruments is ensured by a common data format.


The operating convenience offered by the Trimble 3300DR hardware is very high within this group of total stations. The clear graphic display and only 7 keys give the user a wide variety of information for the processing in the field and provide him with valuable aids for achieving high productivity in solving his surveying tasks.

The software version "Topo¹" meets high standards with the special programs for this application.

¹ topography

⚠ Attention !

Please read the safety notes in chapter 2 carefully before starting up the instrument.



The instrument was manufactured by tested methods and using environmentally compatible quality materials.

The mechanical, optical and electronic functions of the instrument were carefully checked prior to delivery. Should any defects attributable to faulty material or workmanship occur within the warranty period, they will be repaired as a warranty service.

This warranty does not cover defects caused by operator errors, inexpert handling or inappropriate application.

Any further liabilities, for example for indirect damages, cannot be accepted.

User manual:	Edition ver.03.00
Cat. No.:	571 703 151
Date:	October 2004
Software release:	> V 5.61

Subject to alterations by the manufacturer for the purposes of further technical development.

Europe:



Phone: +49-6142-21000

Telefax: +49-6142-2100-220

E-mail:

trimble_support@trimble.com

Homepage:

www.trimble.com

 Tip

The type label and serial number are provided on the left-hand side and under-side of the instrument, respectively. Please note these data and the following information in your user manual. Always indicate this reference in any inquiries addressed to our dealer, agency or service department:

Instrument:

- Trimble 3303DR
- Trimble 3305DR
- Trimble 3306DR

Serial number:

Software version:

We would like to wish you every success in completing your work with your Trimble 3300DR. If you need any help, we will be glad to be of assistance.

Yours



Trimble Jena GmbH
Carl-Zeiss-Promenade 10
D-07745 Jena

Phone: (03641) 64-3200
Telefax: (03641) 64-3229
E-Mail: support_trimble@trimble.com
www.trimble.com

This chapter gives you an overview of the operation and controls of the instrument as well as the programs which are a special feature of the Trimble® 3300DR Routine Total Stations.

Instrument Description	2-2
------------------------	-----

Operation	2-7
-----------	-----

Safety Notes	2-17
--------------	------

From Power to Data	2-23
--------------------	------

Hardware Overview




Fig. 1-1: Trimble 3303 DR, Control side





Fig. 1-2: Trimble 3300DR, Objective side

- 1 Sighting collimator
- 2 Mark for trunnion axis height
- 3 Telescope focusing control
- 4 Vertical clamp
- 5 Eyepiece
- 6 Vertical tangent screw
- 7 Display (graphic capabilities 128 x 32 pixels)
- 8 Interface
- 9 Keyboard
- 10 Horizontal tangent screw
- 11 Horizontal clamp
- 12 Tribrach screw
- 13 Telescope objective with integrated sun shield
- 14 Battery cassette lock
- 15 Vertical axis level
- 16 Battery
- 17 Circular level
- 18 Adjustment screws for optical plummet
- 19 Optical plummet
- 20 Tribrach clamping screw



18

Fig. 1-3: Trimble 3300DR, Optical plummet

The Total Stations Trimble 3303DR, 3305DR and Trimble 3306DR

The electronic Routine Total Stations as instruments of mean accuracy are not only appropriate for land-measuring by geodesists, but also users on building sites appreciate their uncomplicated handling as well as rapidity, reliability and clearness in measuring.

Measurements are made easy thanks to menu guidance supported by graphics, instrument software with flexible point identification and universal data record formats.

The principal features:

Distance measurement

by phase comparison method (PR and DR mode)

Measuring range

up to 100m Direct reflex
up to 5000m/7500 m with 1/3 prism(s)

Angle measurement

Hz and V electronically
all common units and angle reference systems

Error compensation

Automatic compensation of sighting axis and index errors

The advantages in operating

Display screen with graphic capabilities (128 x 32 pixels), user-friendly surface, easy familiarisation, simple handling, reliable control of all measuring and computing processes with clear references, integrated, practical application programs, ergonomic arrangement of controls, light, compact construction

Quick charging, longer times of measuring

Eco-friendly power supply for about 1000 angle and distance measurements, charging time 2 hours

Data management

RS 232 C (V 24) interface as data input and output

Internal data memory of Trimble 3303DR and Trimble 3305DR can record 1900 data lines.

DR Measurement

Direct Reflex Mode and Laser Pointer


In addition to the well known prism mode (PR) the instrument is equipped with:

- Direct Reflex Mode (DR) and Laser Pointer


The Laser pointer can be used to support aiming on any surface in- and outdoor and to search prisms at distances greater than 1000 meters.

⚠ Attention!

Do not use the laser pointer function below 1000 m on prisms and high reflecting surfaces.



DR – Mode measurement without prism




PR - Mode (Standard) - measurement with prism

This program is available on the delivered instrument.

Overview about software version „Topo“


(version > 5.00)



This program version can be selected.


Overview about software version „Construction“

(version > 4.00)




Overview about software "Topo"

Menu (ON+MENU)



- Input
 - 1 — Prism (prism constant)
 - 2 — Scale
 - 3 — Temp (temperature)
 - 4 — Pressure
- Applications
 - 1 — Connecting distance
 - 2 — Object height
 - 3 — Station + Offset
 - 4 — Vertical plane
 - 5 — Area Calculation
- Coordinates
 - 1 — Unknown Station
 - 2 — Known Station
 - 3 — Stationing in elevation
 - 4 — Polar/Detail Points
 - 5 — Stake out
- Setting Instrument
 - 1 — Angle (resolution)
 - 2 — Distance (resolution)
 - 3 — V-Refer
 - 4 — Coord.System
 - 5 — Coord.Display
 - 6 — Temperature
 - 7 — Pressure
 - 8 — Turn off
 - 9 — Sound
 - 10 — Angle (Units)
 - 11 — Distance (Units)
 - 12 — Display Illumination
 - 13 — Contrast
- Dset
 - 1 — DR-Menue
 - 2 — Longe Range
 - 3 — Laser Pointer OFF
 - 4 — EDM-Time-out

Overview about software "Topo"




The Keyboard

Two types of keys:

- Hardkeys
 - direct function
ON and MEAS
 - Key in connection with ON (SHIFT)
- Softkey
function depending on program, significance explained in display line at the bottom

For operating the Trimble 3300DR, only 7 keys are needed.



ON

MEAS

ON OFF

ON DR

ON EDIT

ON PNo

ON MENU

ON

Key Functions (Hardkeys)

Switching the instrument on and changing over to hardkey function

Starting a single measurement or Tracking mode

Switching the instrument off

Switch between PR and DR measure mode

Calling up the memory

Calling up the input of point number and code

Going to the main menu

Switch Laser pointer ON / OFF

Softkeys

Function keys defined by the display in dependence on the program.

Overview softkeys Annex

Using the different EDM Modes DR / PR and Laser Pointer

Direct Reflex Mode



Direct Reflex Mode – DR

When measuring without prisms or any other reflectors. The reflector height is set to Zero (default). If needed this values can be changed in the Menu "INPUT". The prism constant is set to zero to.



Direct Reflex Mode ON

Measuring Range

70 m to Kodak Gray Card- 18% reflection
100 m to Kodak Gray Card- 90% reflection
(depending on the object surface and light conditions).

Prism Mode



Prism Mode - PR

When measuring to prisms or other reflectors like foil. The prism constant and reflector height can be changed in the Menu.



Prism mode ON

Measuring Range:

1,5 ... 3000 m (for 1 prism, Standard range - SR)
1,5 ... 5000 m (for 3 prisms, SR)
2,5 ... 250 m (for foil reflector 60 x 60 mm², SR)

Using the different EDM Modes DR / PR and Laser Pointer

Long Range Mode



Long Range Mode (LR) (DR mode to prisms)

When measuring to prisms or other reflectors at long distances or bad weather conditions. The prism constant and reflector height can be changed in the Menu. "INPUT"



Long Range Mode ON

Measuring Range:

- 1000 5000 m (for 1 prism, LR)
- 1000 7500 m (for 3 prisms, LR)
- 2,5 800 m (for foil reflector 60 x 60 mm², LR)

Note

Prisms should be measured in **Prism Mode**. In this mode the EDM is not so sensitive to disturbing influences and has the highest accuracy.

Attention!

Do not use Direct Reflex Mode on prisms or high reflective surfaces for distances below 1000 m. In that case the prism constant is not taken into consideration.

Error message 042 could appear:

1. doing measurements in DR mode to prisms at distances longer than 300m or distances shorter 1,5m
2. doing measurements in DR mode to non cooperative targets at distances close to the maximum working range in that mode.

Laser Pointer



When aiming to targets or searching targets.



Laser Pointer ON

Direct Reflex Distance Measurement



Appendix
Technical Data

The values given in the technical data concerning accuracy, range and measurement time depend on the following effects:

EDM Modes:



- Atmospheric influences (sight conditions, rain, wavering heat)
- Radiation of the sun at the target
- Disruption of the beam by moving objects


To ensure a maximum result in distance measurement a time out (of the measuring time) has been set to max. 30 sec. This guarantees that even at bad conditions greater distances can be measured. However a measurement takes about 2 seconds.

Tip

If there are unfavourable sighting distances or measuring conditions, you should wait the time – out of the measurement. Every measurement taken within that time matches the accuracy's guaranteed for this mode of measurement.

The range of unambiguity of an indicated measurement covers up to 9 km using prism mode as well as direct reflex mode.


When measuring in direct reflex mode the following measuring area at the target is significant for a measured distance of 50 meters.



When aiming at a target at a distance of approx. 150 m the signal range is approx. 0.13 grad in V- resp. 0,09 grad in Hz- direction. This allows an aiming range of approx. 300 mm in V resp 210 mm in Hz to grant a secure distance measurement. To make sure that there is always enough signal no distance measurement should be taken out of this range.

⚠ Attention!

When using direct reflex mode avoid any interruptions of the beam. If the beam is interrupted while measuring (e.g. shortly by moving objects) the measured distance has to be checked by remeasuring.



When measuring on surfaces with edges within the EDM range make sure to definitely aim to the surface to be measured.

Tip

To separately measure angle and distance or indirectly determine points use programs „Eccentricity / Intersection“.

When measuring greater distances the accuracy of the distance measurement depends on the correction of the atmospheric influences such as temperature pressure and humidity. In order to restrict the atmospheric correction to exactly 1ppm (mm/km) temperature has to be determined up to 1°C, pressure up to 4hPa and humidity up to 20% along the measuring section.

The correction formulas are given in the appendix.



Appendix



Formulas and constants

Tip

Using direct reflex mode be aware of a minimum distance of 1.5 m. If there are unfavourable conditions you cannot fall short of this minimum distance.

The Basic Concept of the Menu

The total station is able to realise a great variety of functions.

Functions needed directly during the measuring process are accessible through the key functions.

ON **MENU**

The menu facilitates the access to many other functions.

Having selected the menu, you can go to submenus and you are offered available functions, respectively:

e.g. settings

```
4 Setting Instr.
↓ 5 DSet
  6 Setting Interface
ESC | ↑ | ↓ | | YES
```



```
1 Angle 0.0005ard
↓ 2 Distance 0.001m
  3 V-Refer zenith↵
ESC | ↑ | ↓ | | MOD
```

e.g. measurement programs

```
↑ 1 Input
  2 Applications
↓ 3 Coordinates
ESC | ↑ | ↓ | | YES
```



```
1 Conn. Distances
↓ 2 Obj. Height+Width
  3 Station + Offset
ESC | ↑ | ↓ | | YES
```

Use of this Manual

The manual is divided into 8 main chapters.

The subchapters have not been numbered. Clarity and convenience are provided by a maximum of 3 structural levels, for example:


Chapter	4 Coordinates
Section	2 Coordinates Unknown Station
<u>Subsection</u>	<u>Recording</u>

Functional text for calling up programs:

4 Coordinates

3 Stationing in elevation

Mode Softkeys and their functions

 Cross references to other chapters



Small graphics

The pages are divided into two columns:

Principal text including


- Description of measuring processes and methods
 - instrument operation and keys
 - Trimble 3300DR display / graphics
 - drawings and large graphics
 - tips, warnings and technical information

 **Tip**

for hints, special aspects and tricks

 **Attention !**

for risks or potential problems

 **Technical Information**

for technical background information

Measuring tasks are defined as follows:

- given: : given values
- meas.: : measured values
- requ.: : required/computed values

You will find a list of terms in the annex (Geodetic Glossary).

Risks in Use



Instruments and original accessories from the manufacturer have to be used only for the intended purpose. Read the manual carefully before the first use and keep it with the instrument so that it will be ready to hand at any time. Be sure to comply with the safety notes.

⚠ Attention !

- Don't make any changes or repairs on the instrument and accessories. This is allowed only to the manufacturer or to specialist staff authorised by the same.
- Do not point the telescope directly at the sun.
- Make sure to strictly observe the following instructions regarding the use of the laser devices.
- Do not use the instrument and accessories in rooms with danger of explosion.
- Use the instrument only within the operative ranges and conditions defined in the chapter of technical data.
- Do not operate the battery charger in humid or wet conditions (risk of electrical shock). Make sure the voltage setting is identical on the battery charger and voltage source. Do not use instruments while they are wet.
- Only the service team or authorised specialist staff are allowed to open the instrument and accessories.

Risks in Use (cont.)

**Attention !**

- Take the necessary precautions at your measuring site in the field, note the relevant traffic rules.
- Check that the instrument has been correctly set up and the accessories are properly secured.
- Limit the time of working when it is raining, cover the instrument with the protective hood during breaks.
- After taking the instrument out of the case, fix it immediately to the tripod with the retaining screw. Do never leave it unfastened on the tripod plate. After loosening the retaining screw again, put the instrument immediately back into the case.
- Prior to starting operation, allow sufficient time for the instrument to adjust to the ambient temperature.
- Tread the tripod legs sufficiently down in the ground in order to keep the instrument in stable position and to avoid its turning over in case of wind pressure.
- Check your instrument at regular intervals in order to avoid faulty measurements, especially after it has been subjected to shock or heavy punishment.
- Remove the battery in case of being discharged or for a longer stop period of the instrument. Recharge the batteries with the charger recommended by the manufacturer.

Risks in use (cont.)

**☞ Attention !**

- Properly dispose of the batteries and equipment taking into account the applicable national regulations.
- The main cable and plugs of accessories have to be in perfect condition.
- When working with the prism rod near to electrical installations (for example electric railways, aerial lines, transmitting stations and others), there is acute danger to life, independent of the rod material. Inform in these cases the relevant and authorised security offices and follow their instructions. Keep sufficient distance to the electrical installations.
- Avoid surveying during thunderstorms because of lightning danger.

☞ Attention !

It is forbidden to use an instrument with optical plummet in combination with a laser tribrach for zenith sighting.

Laser Beam Safety

If used for the intended purpose, and if correctly operated and properly maintained, the lasers provided in the instruments are not hazardous to the eye.

Laser Beam Safety

The EDM in Direct Reflex Mode and in Laser pointer mode produces visible Laser light emerging at the center of the telescope objective.

CLASS 2 LASER PRODUCT

This product complies with IEC 60 825 - 1: January 2001 and 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice no 50, dated July 26, 2001


⚠ Attention

Repairs must only be performed at a service workshop authorised by Trimble.

**DR - EDM in Direct Reflex Mode
Laser pointer**

- Beam divergence: 0,4 mrad
 - Modulation frequency: 300 MHz*)
 - Max. output power: 1 mW
 - Carrier wavelength: 660 nm
 - Measuring uncertainty: ± 5 %
- *) not valid for Laser pointer





⚠ Attention !

Direct viewing into the beam (also with binoculars) must be avoided under all circumstances!

AVOID EXPOSURE -

Laser radiation is emitted from this aperture. Protection is normally afforded by aversion responses including the blink reflex.

Do not use direct reflex mode on prism or high reflective surfaces for distances below 1000 m.

Emergency switches:

- **ESC**
- ON +
- ON + OFF

Laser Beam Safety

The EDM in Prism Mode produces visible Laser light emerging at the center of the telescope objective. Conforms in this mode to CLASS 1 in acc. with IEC 60 825 - 1: January 2001

This product complies with IEC 60 825 - 1: January 2001 and 21 CFR 1040.10 and 1040.11 except for deviations pursuant to Laser Notice no 50, dated July 26, 2001



DR - EDM in Prism Mode

- Beam divergence: 0,4 mrad
- Modulation frequency: 300 MHz
- Max. output power: 17 μ W
- Wavelength: 660 nm
- Measuring uncertainty: \pm 5 %


CLASS 1 LASER

Labelling

The laser beam safety labels are located at the side and front of the telescope objective. The instrument label is located at bottom of the instrument.



Laser beam safety label



Instrument label



Power cable
571905925

Power cable
571908040

Power cable
571905924



External Battery 6V/7Ah
708146-9901
only for Type „ -35° C “



Single Battery Charger
571 906 330



Charger to battery
cable 571208067



Internal Battery 6 V1,3Ah
702504-9040



Power Cable 6V
708177-9480



Data Cable
708177-9460



PC Station

Data Transfer Software
e.g. Terminal program
(Accessories / Windows®)

The *First Steps* cover up the set-up of the instrument, including the explanation of basic inputs and the necessary presettings. After having set the parameters for saving and entered the point information, you can measure in the start-up menu.

Before Measurement	3-2
--------------------	-----


Principles	3-6
------------	-----

Presettings	3-14
-------------	------

Measurement in the Start-up Menu	3-28
----------------------------------	------

Set-Up and Coarse Centring

In order to guarantee the stability of measurement we recommend the use of a heavy tripod.



Set-up:

Extend the tripod legs (1) to a comfortable height of observation and fix them using the tripod locking screws (2). Screw the instrument centrally to the tripod head plate (3). The tribrach screws (4) should be in mid-position.

Coarse Centring:


Set up the tripod roughly above the station point (ground mark), the tripod head plate (3) should be approximately horizontal.

Centre the circular mark of the optical plummet (5) above the ground mark using the tribrach screws.

To focus the circle: Turn the eyepiece.

To focus the ground mark: Draw out or push in the eyepiece of the optical plummet.

Levelling and Fine Centring



Coarse Levelling:

Level the circular bubble (6) by adjusting the length of the tripod legs (1).

Precision Levelling:

Align the control unit parallel with the imaginary connecting line between two tribrach screws.


Level the instrument by turning the tribrach screws a) and b) in opposite directions. Turn the instrument by 100 grad in Hz and level instrument with tribrach screw c).

For checking, turn the instrument round the vertical axis.

After that, check the residual inclination by turning the instrument in both diametric positions of (1) and (2). Take the mean of deviation from centre point of level and adjust, if necessary.

Precision Centring

Shift the tribrach on the tripod head plate until the image of the ground mark is in the centre of the circular mark of the optical plummet; repeat the levelling various times if necessary.

 **Attention !**

It is forbidden to use an instrument with optical plummet in combination with a Laser tribrach for zenith sighting.

Telescope Focusing

Focusing the Crosslines:

Sight a bright, evenly coloured surface and turn the telescope eyepiece until the line pattern is sharply defined.

⚠ Attention !

Sighting of the sun or strong light sources must by all means be avoided. This may cause irreparable damage to your eyes.

Focusing the target point:

Turn the telescope focusing control until the target point is sharply defined.

👉 Tip

Check the telescope parallax: If you move your head slightly whilst looking through the eyepiece, there must be no relative movement between the crosslines and the target; otherwise, refocus the crosslines as above.

Switching the Instrument on

ON

Press key

Additionally to the company logo, the number of the software version (important for future updates) and the values last set for:

- prism constant
 - scale
 - temperature
 - air pressure
- are displayed briefly.

Tip

The compensator is automatically activated when the instrument is switched on.

If levelling of the instrument is insufficient, the digits after the decimal point in the displayed angle readings are replaced by dashes.

Switching the instrument off by pressing the keys

ON

+

OFF

simultaneously.

Principles of Display

The information

- point code,
- point number and
- measured / computed values


is displayed on two pages.

 Toggling between the pages:


 ➔1 to page 1

 ➔2 to page 2

Display page 2:



Display page 1:



Tip

The fields at the bottom of the display are related to the functions of the keys situated below the display.

They indicate the next possible settings - do not mix it up with the current setting.

Principles of Input

Additionally to the setting of predefinitions - as described further down in this chapter - you will have to enter data continually during the measuring process.

These entries are

- the constantly changing instrument, station and reflector heights and
- coordinates of stations or other known backsight points.



Editor

Data Management

The manual input of coordinates is described in **Chapter 6 *Data Management***.




Data Transfer

Data Management


If available, it is useful to transfer the values directly from a PC instead of entering them manually.

Input of Reflector, Trunnion Axis and Station Heights

The input of the values of reflector height (th), instrument height (ih) and station height (Zs) (height-stationing) allows you to measure with absolute heights already in the initial menu. If these values have not been entered, only relative height differences will appear in the display (memory). If Zs=0 the height difference "h" is displayed and recorded, otherwise the height "Z".




on display page 1 only:



th/ih in measuring modes HD and yxh only

Presettings
First Steps



ESC to quit
Z heightstationing

th to enter the reflector height

ih/Zs to enter the instrument and station height

o.k. to confirm



Heightstationing: Input of th and ih/Zs

- ┌ th 2.000 m
actual refl. height
- ┌ th-old 0.100
last refl. height
- ┌ th=0
set to zero
- ┌ input
to enter a value

Input of the reflector height:



- ← and
- to go to the desired position in the display
- +
- to browse through the digits
- o.k. to confirm

Set reflector height via input




The current position for input is inverse displayed.

⚠ Attention !

Default Settings in DR mode:
 th=0.000 m
 Prism constant=0.000m

- ┌ Editor
Data Management
- ┌ to enter values
(compare input of th)
- ESC to quit the input routine

Input of the instrument height / station height



Measurement „Stationing in Elevation“

Stat to go to the input menu




CHCK  Adjusting and checking


ESC to quit the program



Input one after the other:

Z, ih, th:

  Principles
First Steps
 Editor
Data Management



Measurement to the backsight point

→ sight to the backsight point


ON + **PNo**
enter or change of the point number



MEAS

YES to accept the result, to record data, to quit the program

NO to terminate the program, new start




Result and Recording

Input of Point Number and Point Code



indicates the possibility to enter point number and code.



and



to go to the desired digit of point number and code



and



to browse through the existing character set



The entered values are used with the next measurement.

- C 5-digit point code, alphanumeric notation
- P 12-digit point number with the special characters #, -, ., , .numeric notation

Tip

The toggling between point number and code is realised continuously.

For fast browsing, keep the respective key depressed.

After the measurement, the point number is incremented by one, the code remains unchanged until being modified by the user.

In the application and coordinate programs, the code is provided with fixed characters (A,B,..) responding to the application or coordinate program. In this case, it is not possible to enter the code.

Principles of Distance Measurements

Single measurement

Indicates the measurement in progress.

MEAS start measurement in DR mode



The distance measurement can be cancelled with the softkey ESC.

Presettings
First Steps

The slope distances and derived values are corrected with regard to the influences of earth curvature / refraction. Additionally, a correction of atmospheric influences (temperature and pressure) is applied.

The correction is zero with T = 20°C and P = 944 hPa.

Distance tracking (continuous measurement of the distance)


MEAS start tracking

To activate the "Distance tracking mode" press the key **MEAS** twice!

END to finish the measurement

The measuring mode can also be changed during the tracking measurement. For recording data during the tracking measurement use key **MEAS**.

yxh to change the measurement mode




Measurements to inaccessible Points

Tip

Please use this function in the start-up menu only.

In the program "Polar/Detail Points" it is possible to measure with the program "Eccentric Measurement".

The prism used for the distance measurement cannot be stationed on the desired point P.



Sight towards the point P and trigger the measurement. Then aim to the prism stationed on the auxiliary point H. Pay attention to the condition of equidistance $S-P = S-H$.

If data recording is activated, only a data line indicating the angle to P and the distance to H is recorded.

But after the measurement the angle and distance to H are displayed, since the angle value is continuously updated in the Trimble 3300DR display.

Introduction

The required presettings are to be subdivided into three groups:

Settings in the Start-up Menu

- Specify measuring units for angle and distance
Short-time setting of V angle in percent
- Toggle between PR and DR mode
- Laser pointer ON / OFF
- Activating and deactivating the compensator
- Orientation of Hz circle
- Activating program "Intersection" (INT)

Frequently used Settings

- Input of pressure and temperature
- Input of scale and prism constant
- DR menu ON

Rarely used Set Instructions

- Display mode for angle and distance
- Vertical reference system
- System of coordinates
- Display of coordinates
- Measuring units of temperature, pressure
- Switching the instrument automatically off
- Switching the acoustic signal on and off
- Regulation of display contrast and brightness of crossline illumination
- Switching the distance measurement off automatically if sighting line interruption
- Long range (LR)


Settings in the Set-Up Menu

Setting the unit of distance measurement

Setting of the units for angle and distance measurement can be done in the menu "Setting Instrument". Setting the units for distances can also be done in the measurement menu.

Display page 2

- F1** to set the distance unit
- m** meters
- ft** feet





⚠ Attention !

If the mode is changed after the measurement, the reading will be converted and displayed in the new mode immediately. But results of the measurement in the new mode are recorded after the next measurement.

Display page 1

- V%** and
- V↔** to toggle quick between angle in percent / defined measuring unit



Activating and deactivating the compensator

CHCK to go to the menu


c/i and

Comp  Adjustment and checking

C-on to deactivate the compensator function

C-off to activate the compensator function

Display page 2:



Display compensator menu:



If recording is activated, an information line will be stored indicating compensator function ON or OFF.

⚠ Attention !

If the compensator is out of its working range and the function is activated, the digits after the decimal point in the angle readings are replaced by dashes. In this case, the instrument is not sufficiently levelled and a remote release from a PC is not admitted.


Orientation of Hz circle

Aim: Hz = 0

Hz=0

Sight to target

MEAS



Aim: Hz = xxx,xxx


HOLD

Turn the instrument to the desired Hz circle value

MEAS

Sight to target

MEAS



Display page 2


Aim: Change Hz count direction

→Hz

Measurement clockwise

←Hz

Measurement counterclockwise









Attention !

Setting of the Hz count direction is only possible in the start-up menu. The Hz count direction is always recorded to clockwise. After switch ON the instrument and in all selectable programs the default setting of the Hz count direction is always to clockwise.



Frequently used Settings

ON + MENU

1 Input

-  and
-  to go to the desired menu point
-  to confirm
-  and
-  to alter the prism constant (scale, temperature and pressure) step by step
-  to confirm


Alteration of pressure, temperature, scale and prism constant



Tip

After switch ON the instrument only temperature and pressure have to be entered.

If a prism with a constant different from -35 mm is used the new prism constant also has to be entered.

 Formula and constants
Annex

Possible ranges:

-30 °C	< Temp.	< 70 °C	with Δ 1 °C
-162mm	< Prism.	< 92mm	with Δ 1 mm
0,995000	< Scale	< 1,005000	with Δ 1 ppm
440hPa	< Press.	< 1460 hPa	with Δ 4 hPa

Rarely used Settings

ON + MENU

Select the main menu.

4 Setting Instrument

YES to activate menu

↑ and


↓ to select the submenu

MOD to change setting


ESC to quit submenu

↑ and

↓ to quit setting / to confirm change



Angle and distance display



Possible settings:

Angle

- grad 0,005-0,001-0,0005 (Trimble 3305DR / 3306DR)
- grad 0,005-0,001-0,0002 (Trimble 3303DR)
- DMS 10" - 5" - 1"
- deg 0,005° - 0,001° - 0,0005°
- mil

Distance


- m 0,01-0,005-0,001
- ft 0,02-0,01-0,001

⚠ Attention !

The selected settings of angle and distance accuracy are only related to the display. Measurements are always recorded with the highest possible precision.


- MOD** to change setting
- ESC** to quit menu
- ↑** and
- ↓** to quit setting / to confirm change

Vertical reference system



V reference systems:


↙ Zenith angle



Examples


1: Zenith angle
unit 400 grads

↘ Vertical angle



2: Vertical angle
unit 360°

↖↗ Height angle



Examples

3: Height angle
unit 6400 mil

👁 Tip

The setting of the measuring unit % is done in the set-up menu!


- MOD** to change setting
- ESC** to quit menu
- ↑** and
- ↓** to quit setting / to confirm change

System of coordinates / display order

```

4 Coord. Syst. Y↑→X
↓ 5 Coord. Displ. Y,X
6 Temperature °C
ESC | ↑ | ↓ | MOD
    
```

Assignment of axes of system of coordinates:



Indication sequence: Y-X / X-Y E-N / N-E

⚠ Attention !

When the assignment of coordinates is changed, the question for further use of the internal station coordinates appears in the display, calling the user's attention to a possible source of errors.

- MOD** to change setting
- ESC** to quit menu
- ↑** and
- ↓** to quit setting / confirm change

Measuring units for temperature / pressure

```

6 Temperature °C
↓ 7 Pressure hPa
8 Turn Off OFF
ESC | ↑ | ↓ | MOD
    
```

Possible settings:

Temperature	°C	degrees Centigrade
	°F	degrees Fahrenheit
Pressure	hPa	hectopascal (or millibar)
	Torr	
	inHg	inch mercury

- MOD** to change setting
- ESC** to quit menu
- ↑** and
- ↓** to quit setting / confirm change

- MOD** to change settings
- ESC** to quit the menu
- ↑** and
- ↓** to quit settings / to confirm alterations

- MOD** to change settings
- ESC** to quit the menu
- ↑** and
- ↓** to quit settings / to confirm alterations


Acoustic signal



Possible settings:

Sound ON- OFF

Settings of units for angles.



Possible settings:

Angles	Grad	400.0000
	DMS	360° 00' 00"
	deg	360.0000°
	mil	6400mils

Settings of units for distances



Possible settings:


Distances	m	Meters
	ft	Feet

Tip

It is possible to change the units between meters and feet in the start up menu.

- MOD** to change settings
- ESC** to quit the menu
- ↑** and
- ↓** to quit settings / to confirm alterations

Display illumination / Reticle illumination



Possible settings:


Disp. Illum.: ON- OFF

Tip

Both illuminations are switched on at the same time. The adjustment of the reticle illumination is only possible with the display illumination switched ON.

- MOD** to change settings
- ESC** to quit the menu
- ↑** and
- ↓** to quit settings / to confirm alterations

Displaycontrast /Reticle illumination variation



Possible settings:

Contr / Illum: 8 steps

Tip

The adjustment of the display contrast is only possible with the display illumination switched to OFF. The adjustment of the reticle illumination is only possible with the display illumination switched ON. To switch ON the reticle illumination please switch ON the display illumination to

ON + **MENU**

5 Dset

YES to activate menu

↑ and

↓ to select the submenu

MOD to activate menu

ESC to quit submenu

↑ and

↓ to quit setting / to confirm change

MOD to activate menu


ESC to quit submenu

↑ and


↓ to quit setting / to confirm change

Select the main menu.

Setting modes and parameters related to the EDM / distance measurement.



DR mode (Support programs for DR mode)




Possible modes: Standard->Start
Bearing->Distance
TRK->Start

Tip

The modes of the menu appear after pressing the button **MEAS** !

Long Range (measure long distances).



Maximum ranges: 800m for foil reflector (60x60 mm²)
5000m for 1 prism
7500m for 3 prisms

MOD to activate menu

ESC to quit submenu

↑ and

↓ to quit setting / to confirm change

Laser Pointer OFF

1	DR-Menu	NO	
↑ 2	Long range	NO	
3	L-Pntr OFF	NO	
ESC	↑	↓	MOD

Possible settings:

- No - Laser pointer always ON.
- 1x - Laser pointer OFF after measurement or after 2 minutes without measurement.

Tip

This setting controls the time to switch the laser pointer OFF automatically.

YES to activate menu

ESC to quit submenu

↑ and

↓ to quit setting / to confirm change

Time out distance measurement

2	Long range	NO	
↑ 3	L-Pntr OFF	NO	
4	EDM T-Out	30sec	
ESC	↑	↓	MOD

Possible settings:

- OFF - No Time out EDM
- 10sec. - Time out after 10 seconds
- 30sec. - Time out after 30 seconds

Tip

This setting controls the time out of the distance meter while the distance measurement is interrupted.

Recording the Measurement

ON + MENU

6 Setting Interface

YES to enter the menu



MOD to toggle between MEM/1, MEM/2, MEM/3, V24/1, V24/2, V24/3, OFF

ESC to return to the higher-order menu



MEM/x - internal saving (only Trimble 3303DR and Trimble 3305DR)

V24/x - external recording via RS232 interface

Off - no recording

1 - recording of measured values

2 - recording of computed values

3 - 1 and 2 together

Attention !

These settings are valid in the programs „Coordinates“ and „Applications“.

All results in the Start-up menu are interpreted as measured values (1).

Record data lines Data Management

Tip

The detailed depiction about the relationship of measured data, recorded type of identifiers and selected recording are described in the chapter Data Management.

 Presettings
First Steps

 Attention !


Depending on the selection of type of recording and type of measuring mode the type of displayed results and the type of recorded values is given.

Recording default values (Header) and changed settings

ON + **MENU**

Select main menu

6 Setting Interface



YES to enter the menu

↑ and

↓ to quit setting / to confirm change


ESC to return to the' higher-order menu

MOD to toggle YES/NO

ESC to quit submenu

↑ and

↓ to quit setting / to confirm change

 Record data lines
Data Management



Possible settings:

- YES - Record settings
- NO - Don't record settings

 Tip

The detailed depiction about the relationship of measured data, recorded type of identifiers and selected recording are described in the chapter Data Management

ON

YES to activate

NO to deactivate

Record current settings?



Attention !

To start recording switch OFF and ON again the instrument!

Selecting the Measuring Mode (presentation of the results at the display)

F1 to set the following measuring modes


Display page 1:

Tip

At the display of softkey 1, always the next selectable measuring mode appears.

SD: Display of the original measurement


Status display:



F1 F2 F3 F4 F5

HzV: Display in the theodolite mode

Can be used for alignments and for setting out right angles but not for distance measurements.



HD,HZ,h: Display of the reduced distance and the height difference

Display of the calculated values with Z=0

↙	HD	3.836m	
→	HZ	118.3195grd	(C+P)
↘	h	2.609m	
y/xh Hz=@ th/ih INTS →2			

with Z≠0

↙	HD	3.941m	
→	HZ	355.9755grd	(C+P)
	Z	150.065m	
y/xh Hz=@ th/ih INTS →2			

y,x,h: Display of the local rectangular coordinates

Measurement in the local system with station y=x=0 with Z=0

	y	3.678m	
	x	-1.089m	(C+P)
	h	2.609m	
SD Hz=@ th/ih INTS →2			

with Z≠0

	y	3.675m	
	x	-1.088m	(C+P)
	Z	150.050m	
SD Hz=@ th/ih INTS →2			

👉 Tip

The measuring modes can be changed at any time. The results will be displayed immediately in the selected measuring mode but these results are not recorded at the same time. All following measurements are displayed and recorded in the newly selected mode.

In all measuring modes, the angle reading is updated continually.

The measured distances or coordinates are updated only after the next measurement.

Measurement

After entering and defining all required parameters the measurement can be started.

MEAS


etc. Measurement to further points

ON

PNo

Input point number and code

MEAS




Measurements in the modes

SD and HzV are done without entering and recording local or global heights

Tip

After the measurement, the flush right point number is incremented by one within the number of digits displayed up to the special characters (no figure) to the left of it. (According to this picture, counting goes only up to 9, then it will begin again with "0".)



Display with absolute heights, with the heights Zs, ih and th entered.

The basic requirement for a measurement in a system of coordinates is a stationing within this system before. That means the position and height of the instrument are determined by measuring to known backsight points.

In the case of an unknown station, the scale and the orientation of the Hz circle in azimuth direction are computed additionally to the station coordinates. In the case of a known station, only the scale and the orientation of the Hz circle in azimuth direction are computed.

After the stationing, the actual measurements - that means Polar/Detail points and Stake out - can be done within this system of coordinates.

The Menu Guidance 4-2

Unknown Station 4-6

Known Station 4-11

Stationing in Elevation 4-15

Polar/Detail Points 4-18

Stake Out 4-29

The guidance through the menu is very easy to understand and based on a unique schema for all programs.

Principle

Coordinates

Unknown station

Each program flow is demonstrated by a graphics.

A and B are backsight points with known coordinates and S is the station the coordinates of which are to be calculated.




CHCK  Adjusting and Checking

A to call point A




 Tip

The function of adjusting and checking is required for measurements to be carried out without/with compensator or for checking the adjustment of the instrument.

  Principles
First steps
 Editor
Data management

Coordinates are to be entered



- B** to continue by calling point B
- ESC** to return to the higher-order menu
- A** to repeat point A if required



If A has been calculated, measured, defined as station, the symbol for A is filled.

⚠ Attention !


If errors or confusions should occur whilst measuring to the points, the measurement to single points can be repeated immediately.

- ON** + **PNo** to enter point number and code
- MEAS** to trigger measurement

💡 Tip

Prior to each measurement with **MEAS** it is possible to enter a point number and a code for the point to be measured. In the stationing programs, the codes (A, B, C, D, E, S) have been invariably set. Point numbers can be entered. The point number is incremented automatically by 1. The code that has been set is saved with every measurement until being modified by the user.

In the Stake out program, the possibility to measure is indicated additionally by the **MEAS** symbol in the display



Station Point Memory Trimble 3303DR / 3305DR

In a non-volatile instrument memory, the following data are retained after switching the instrument off and overwritten with every new determination:

Station coordinates	Y,X,Z
Instrument height	ih
Reflector height	th
Scale	m
Orientation	Om

The coordinates of the station point are calculated or entered by means of the coordination programs.


During the following operations (Stake-out / Polar/Detail points), the user can access this memory at the respective parts of the program and does not have to enter the values again. After having changed the station, these values have to be calculated or again entered in the course of the program.

Special Features of Trimble 3306DR

The Trimble 3306DR (the instrument is not fitted out with a data memory) has a memory location for another single point (coord-memory) containing the coordinates of this point (Y;X;Z) in a non-volatile form.

This memory location permits a simple transmission of coordinates (stationing with "Unknown station") with the Trimble 3306DR and spares the user the trouble to take the coordinates down or to enter them twice.

Trimble 3300DR
principle
of transmission of
coordinates
„Unknown station“




Window of the Trimble 3306DR when calling coordinates



Method:

The station coordinates S1 are known or have been calculated by means of a coordinate program. The coordinates of point K1 will be calculated with the program „Polar/Detail Points“ and saved in the „coor-memory“ with **CMem**.



After placing the instrument on S2, the coordinates of the points S1 (last station) and K1 (coor-memory) are called with the stationing program "Unknown station" and used for determining the coordinates of S2.

Now, the coordinates of the point K2 can be calculated with the program "Polar/Detail Points" and stored in the "coor-memory". After changing the position of the instrument to S3, the coordinates of this point will be calculated in analogy to station S2.


Coordinates

Unknown Station

If it is not possible to occupy a point with a known position in order to sight the points to be surveyed or set out, a free stationing can be carried out.

If all backsight points have a known height, the Z coordinate can also be determined simultaneously. A maximum of 5 points can be measured!

All measurements have to be done in combination with a distance measurement




- given: : $(Y, X, Z)_{A...E}$
- meas.: : $(SD, Hz, V)_{S-(A-E)}$
- requ.: : $(Y, X, Z)_s, Om, m$

By measuring to 2..5 known **B**acksight **P**oints (A.. E), the instrument will calculate the station coordinates X_s, Y_s, Z_s the Hz circle orientation **Om** and the scale **m**.


The following description is done for a stationing "with stationing in elevation". The procedure without stationing in elevation is almost identical.

Stationing in Elevation

- ESC** to go to the coordinates menu
- L** with: input of instrument height
- L** without: no calculation of height
- L** Principles First steps
- L** Editor Data management



Input of instrument height



☞ Note !

In a free stationing with height determination, all backsight points must have a height coordinate. It is not possible to use individual backsight points separately according to position and height. The height is calculated by simple averaging.

☞ Tip !

If not all backsight points are provided with a height coordinate, the method **without height** is to be applied. Subsequently, the station height can be determined separately by measurement to one point using the "Stationing in elevation" program.

Measurement „Unknown Station“






A to select BP A


CHCK  Adjusting and checking

ESC to quit the program



Selecting the coordinates of BP A

-   Principles
-  First steps
-  Editor
-  Data management



th to enter data for BP A (target height)

ON + **PNo** Point number of BP A to be changed?

MEAS to measure to BP A

B to select BP B

A Measurement to BP A to be repeated?



[sight reflector icon] -> + - Sight reflector



The operational steps for BP B...E are now carried out in analogy to BP A.

After at least 2 measurements, approximate coordinates are calculated by software and the deviation to the current measurement is displayed.

ESC to quit the program

B Measurement to BP B to be repeated?

C to measure the next point (E=5.)

END to display the residuals



Explanation:
vy: Residual in Y-direction
vx: Residual in X-direction
vz: Residual in Z-direction

Tip !
Consequently, residuals can also be used to "Stake out" (seek) points, because the measurement of point can be repeated immediately.

Coordinates

Unknown Station

- More** to measure additional point
- ↑**, **↓** to select point
- Del** to delete point
- o.k.** to display station coordinates
- o.k.** to display further parameters

ON + **PNr** to enter the point number of the station

Rept to repeat the complete determination

m to edit the scale

o.k. to accept the coordinates, complete the program and go to the coordinates menu; to record

Display of residuals:

Vy	0.000m			
Vx	0.000m			A
Vz	-0.010m			
More	↑	↓	Del	o.k.

Point to which the residuals belong

After confirming the residuals:

Ys	1000.002m			
Xs	999.998m			
Zs	0.000m			
				o.k.

Display of the station coordinates:

m	0.996194			
Om	399.9960910		(C+P)	
s0	0.000m			
Rept		m		o.k.

Explanation:

m: calculated scale

Om: orientation unknown

s0: standard deviation of the weighting unit (mean point error)

Note !

It is possible to go backwards and re-measure the corresponding points, whereby the intermediary points get lost.

But it is more recommendable to complete the measurement (calling the residuals) after three backsight points, delete and re-measure the corresponding direction. New measurements are added at the end.

Consequently, the assignment of the point codes (A, B, etc.) are shifted.

- scale
- +** to edit
- o.k.** to accept scale, to go to the residuals menu

Scale menu



If the scale is outside the permissible range, an error message appears.

Note !

After the scale has been confirmed, the station coordinates are recalculated. Then, the residuals can be evaluated once more.

Recording

Presettings First steps

If recording is activated, the following lines are saved in dependence on the settings:

Designation of the mode

Point numbers and code

backsight point A, B, C, D, E

Y,X,Z Coordinates

SD,H,z,V Readings

vy,vx,vz backsight point residuals

Y,X,Z Coordinates of station point S


m,Om Scale and circle orientation

s0 Standard deviation of the weight unit

Coordinates

Known Station

If it is possible to occupy a point with a known position in order to sight the points to be surveyed or set out, a stationing on a known point can be carried out.




- given: : $(Y, X)_{S,A}$
- meas.: : $(SD, Hz)_{S-A}$, or $(Hz, V)_{S-A}$
- requ.: : Om, m or Om

By measuring to a known **B**acksight **P**oint **A**, the instrument will calculate the circle orientation **Om** and the scale **m**.


Measurement „Known Station“

- S** to call station S
- CHCK** Adjusting and checking
- ESC** to quit the program



Selecting the coordinates of station S

- L** Principles
- First steps**
- Editor
- Data management**



After defining S:

There are two ways to calculate the orientation.

- Hz** see below
- XY** page 4-11
- S** to repeat station S




Orientation using a known Azimuth

The orientation using a known azimuth will be selected if the bearing angle between the station and the backsight point is known (for example calculated from coordinates) and a distance measurement to the backsight point is impossible.


↷ to set the required direction by turning the instrument

MEAS to clamp the Hz set direction




→ to sight the known point

MEAS allocation is completed



YES to confirm, record, quit the program

NO to reject, new start




Display of results and recording

Orientation using known Coordinates

This orientation method will be used if the coordinates of the backsight point are known.

Selecting the coordinates of BP A

- └ Principles
First steps
- └ Editor
Data management



- └ SD/Hz/V
Distance and bearing measurement
- └ Hz/V
Bearing measurement




- [ON] + [PNo] Point number of BP A to be changed?



- [MEAS] to BP A

- [YES] to confirm the orientation, continuation




- [NO] to reject the orientation, new start

new to accept the new scale

old to transfer the orientation accepting an old scale

Inp to transfer the orientation entering any scale

Rept to repeat the calculation



Display of results and recording

Recording

 Presettings
First steps

If recording is activated, the following lines are saved in dependence on the settings:

Designation of the mode

Point numbers and code

Y,X Coordinates of station point

Y,X Coordinates of backsight point A

SD,HZ,V Readings for backsight point A according to selection

m,Om Scale and circle orientation according to selection


HZ HZ set direction

V Vertical angle at HZ

Coordinates

Stationing in elevation

Stationing in elevation permits the determination of the height above Mean Sea Level independently of planimetric stationing. In programs involving local coordinates, in particular, the absolute height can be included in the measurement.



- given.: : Z_p
- meas.: : $(SD, V)_{S-P}, ih, th$
- requ.: : Z_s

The station height is determined by measurement to a Backsight Point with a known height.



Measurement „Stationing in Elevation“

- Stat** to go to the input menus
- CHCK** Adjusting and checking
- ESC** to quit the program



Enter one after another:


Z, ih, th:

- └  Principles
First steps
- └  Editor
Data management



- └ th 0.850 m
Confirmation of the old value
- └ th=0
Set to zero

Example th:




- Sight backsight point
- ON + PNo
Point number to be changed?



MEAS

YES to confirm, record, quit the program

NO to reject, new start



Display of results and recording

Recording

 **Presettings**
First steps

If recording is activated, the following lines are saved in dependence on the settings:

Designation of the mode

Point numbers and code

th Reflector height at backsight point
(only if changed)

ih Instrument height (only if changed)

Z Height of backsight point

SD, Hz, V Readings for backsight point

Zs New station height

Zi Hight of sight line (trunning axis)



Coordinates

Polar/Detail Points

Determination of the coordinates and heights of new points by distance and direction measurements.

The coordinates can be computed in a higher-order system of coordinates.

Local coordinates can be determined in the standard measurement menu.



given.: : $(Y, X, Z)_S, Om, m$

meas.: : $(SD, Hz, V)_{S-P}$


requ.: : $(Y, X, Z)_P$

Confirmation of Stationing

YES to confirm the station coordinates and to continue in the program

NO to reject, new start - stationing

m to change the scale



Coordinates

Polar/Detail Points

+ **-** to change m

o.k. to confirm

YES to confirm and continue in the program

NO to reject, restart - stationing

YES to confirm and continue in the program

NO to reject, new start - height stationing

ih/Zs to enter instrument and reflector heights

Scale:

scale	1.000	115
corr.		115ppm
+	-	o.k.

Reference direction:

Reference dir.	o.k. ?
H _Z	303.8255 yrd
NO	YES

Instrument and station heights:

ih	1.000m
Z _s	157.950m
NO	ih/Z_s YES

⚠ Attention !

If neither a stationing in elevation has been realised beforehand nor Z_s is entered now, all heights Z will be related to the station height Z_s=0.

If ih is not entered either, all heights Z will be related to the trunnion axis height Z_i=0.

Measurement „Polar/Detail Points“

→1 **→2**

to change pages over



ECC

eccentric measurement

INTS

to activate software Intersection



th

to enter the reflector height of the new point

ON + **PNo**

to enter point number and code of the new point

Display of results and saving



CHCK



Adjusting and checking

MEAS

to start the measurement




☞ Tip

The measurement can be triggered both on display pages 1 and 2. After the measurement, the program returns to the page where the measurement has been triggered.


Eccentric Measurement

If points cannot be measured directly, the eccentric measurement option can provide the solution. Spatial eccentric target measurements are very helpful especially for indoor surveys.

- Inp** to enter the length
- MOD** to change the mode
- o.k.** to accept
- ESC** to quit the menu



spatial eccentricity



position eccentricities

The graphics does not change !



Type of target eccentricity (softkey **MOD**):

- Tv: in front of the centre
- Th: behind the centre
- Tl: left of the centre
- Tr: right of the centre
- Ts: spatial relative to the centre

Viewing direction:
Centre of the instrument !

Note !

Height calculation is based on the assumption that centre and eccentricity have the same level. This does of course not apply to the Ts type (spatial) (calculation of the real height of the centre).

Display before eccentric measurement is started



Note !

The eccentricity set is effective only once.

Intersection

To measure edges and corners in DR mode it is recommended to use the program „Intersection“.




INTS select Intersections



L to select / activate mode – Corner-Angle mode – Intersection mode – Eccentric Object

Activate one of three programs to measure edges or corners.



Corner-Angle

This method is used to measure points, edges and corners on vertical planes.

A measure points to determine the plane by


Measurements to the points A and B can be repeated.

B using angle and distance measurement

Any point of the plane can be measured.

P angle measurement to determine P

MEAS measurement



Intersection perpendicular

- A**, measure points
- B** to determine the first plane
- C** and the second plane
- P** point of the corner (inner or outer) to be measured

MEAS measurement




This method is used to determine the intersection point of two vertical planes. The planes do intersect under a perpendicular angle.

Measurements to the points A, B and C can be repeated.

Result of the measurement is the coordinate of bottom point of the corner.

In the set of original measurements only the horizontal angle is recorded!



Intersection general

- A**, **B** measure point
- C**, **D** to determine both planes
- P** point of the corner (inner or outer) to be measured

MEAS measurement




This method is used to determine the intersection point of two vertical planes. The planes do intersect under a general angle.

Measurements to the points A, B, C and D can be repeated.

Result of the measurement is the coordinate of the bottom point of the corner.

In the set of original measurements only the horizontal angle is recorded!



Eccentric Object

A **B** measure point
of the object
Center point
and radius are
calculated

MEAS measurement



This method is used to determine the radius and the centre point of a vertical round object.

Measurements to the points A and B can be repeated.

Result of the measurement are the radius and the original measurements / coordinates of the centre point of the round object.

☞ **Note !** There is no need anymore to select the point to be measured in the menu before measurement. Just aim to the target and start measurement!

☞ **Note !** The DR support programs "INTS" are only accessible for the coordinates program "Polar/Detail Point" and in the measurement menu!

⚠ **Attention !**
Default Settings in DR mode:
th=0.000 m
Prism constant=0.000m

DR-Menu

To activate even more programs to support the DR mode.



DR-Menu

SHIFT + **MENU**

Dset


DR-Menu

YES to select this menu



MEAS to call on menus of DR-Mode

- mode – Standard→Start
- mode – Bearing-Distance
- mode – Tracking→Start




Standard→Start

L to select / measure



Direct / standard measurement in DR mode.

Note ! Just aim to the target and start measurement pressing the button "Standard-->Start"!



Bearing-Distance

1. First measurement bearing
2. Second measurement distance

MEAS measurement

MEAS measure bearing to the corner

MEAS measure distance close to the corner





This method is used to determine a corner.

First measurement is done to the corner and second measurement is done close to the corner.

Result of the measurement are the original measurements / coordinates of the corner point.

Note ! There is no need anymore to select the points A and B before to be measured in the menu measurement. Just aim to the target and start measurement!



TRK→Start

 to select / measure

MEAS record results

Tracking mode



☞ **Note !** Just aim to the target and start measurement pressing the button "TRK-->Start"!

☞ **Note !** The modes Standard->Start
Bearing-Distance
are usable in the programs "Coordinates"
and "Applications" while the mode
TRK->START
is furthermore usable in the programs
"Polar/Detail" point and "Stake out" and in
the measurement menu.

Recording

 Presettings
First steps

If recording is activated, the following lines are saved in dependence on the settings:

Designation of the mode

Point numbers and code

m Scale (only if changed)

ih Instrument height (only if
changed)

Zs Station height (only if changed)

th Reflector height at backsight point
(only if changed)

Tv,Th,Tr,Tl,Ts Eccentricity


SD, Hz, V Polar coordinates

Y, X, Z Rectangular coordinates


Coordinates

Stake Out

Search points or stake out points in a given system of coordinates. A stationing is the prerequisite for stake out points on the basis of coordinates.




After having entered the coordinates of the point to be stake out and measured the approximate point, the Trimble 3300DR displays the result in the form of the longitudinal deviation dl , the transverse deviation dc , the angle H_z between the approximate point and the nominal point, the radial deviation dr and the deviations of the coordinates dx , dy and dz .



- given.: : $(Y,X)_{S,P}$
- comp.: : $(HD,H_z)_{S-P}$
- meas.: : $(HD,H_z,V)_{S-N}$
- comp.: : $(dl,dc,dr)_{P-N}$

Confirmation of Stationing

- YES** to confirm the station coordinates /continue program
- NO** to reject, new start - stationing
- m** to change scale



+ **-** to change m

o.k. to confirm


Scale:



YES to confirm and continue in the program

NO to reject, new start - stationing


Reference direction:



YES to confirm and continue in the program

NO to reject, new start - height stationing

Instrument and station heights:



ih/Zs to enter instrument and reflector heights

Measurement „Stake Out“

The following options for the stake out method are available:

```
Stake out
Z: on
ESC YXZ HDh CHCK Z-0
```

or

```
Stake out
Z: off
ESC YX HD CHCK Z-1
```

CHCK



Adjusting and checking

Z-n

Z-j

Change with / without height

YXZ

YX

see below

HDh

HD

page 4-32

Stake out with or without height

Stake out using given coordinates

or

using known stake out parameters

Stake Out using known nominal Coordinates



Principles
First steps



Editor
Data management

```
Internal memory
input
ESC
```


↘ to turn the instrument up to Hz=0

th to enter the reflector height

ON + PNo Point number and code to be corrected?

MEAS to measure the approximate point

After defining the coordinates:



to continue see measurement results page 4-33

Stake Out using known Stake Out Parameters

L HD 4.152 m Confirmation of the old value

L HD=0 Set to zero

L Principles First steps



Entering HD:



↘ to set the desired Hz value

MEAS 1st measurement to the approximate point

Defining the Hz value:



Coordinates

Stake Out

ON + **PVo**

Point number and code to be corrected?

th

to enter reflector height

```

HD          4.152m
Hz         -156.8875grd (C+P)
1)Hz---->0 2)MEAS
ESC        CHCK
    
```

Measurement results see below

Measurement Results

→

to change over the different displays of results

Test

see below

o.k.

to confirm the stake out and to record;
to set out other points

```

dl          0.005m
dc          0.000m
dr          0.005m MEAS
ESC        Test  →  o.k.
dy          0.004m
dx          -0.003m
Hz          0.0025grd MEAS
ESC        Test  →  o.k.
dz          0.051m
Hz          0.000090n MEAS
ESC        Test  →  o.k.
    
```

Display of results / recording

MEAS

to repeat until the approximate point is close enough to the stake out point!

th

to enter the reflector height

MEAS

to measure

Additional measurement of the stake out point (**Test**):

```

Y          0.000m
X          0.000m
Z          0.000m
ESC        S-O th
    
```

Display of results / recording

S-O Setting out, calling up next point

```

Y  4400003.846m
X  5800000.364m

ESC  S-O  th
    
```

Display of results and recording

Recording

 Presettings
First steps

If recording is activated, the following lines are recorded in dependence on the settings:

Designation of the mode

Point numbers and code

HD,HZ, Z or Nominal values

Y,X,Z

SD,HZ,V Readings for the point

dI, dC, dR Stake out differences

dY, dX Stake out differences (only if nominal coordinates are used)

dZ Stake out differences (only if the height is set out)

or

th Reflector height (only if changed)

SD,HZ,V Readings and

Y,X,Z Actual coordinates of check measurement

The chapter *Applications* describes typical configurations and computations for various measuring methods that are frequently used in practice.

The Menu Guidance 5-2

Connecting Distance 5-5

Object Height + Width 5-10

Station + Offset 5-14

Vertical Plane 5-23

Area Calculation 5-28


The guidance through the menu is very easy to understand and based on a unique schema for all programs.


Principle

Applications

Conn. Distances

In the Connecting Distance and Station + Offset programs, the height reference can be established by a stationing in elevation (with) or by a measurement to the first point (without). The Object Height and Vertical Plane programs have own modes for a height reference.

L with
 Coordinates Stationing in Elevation see page 4-15 without to start the program



ESC to quit the program

After calling the respective program, a graphics appears with a detailed explanation of the program.


CHCK  Adjusting and checking

A to start the program by calling point A



☞ Tip

The function of adjusting and checking is required for measurements to be carried out without/with compensator or for checking the adjustment of the instrument.



The display of A in negative type indicates the possibility to measure to point A.

ON + **PNo**

to enter the point number and code

MEAS

to trigger measurement

☞ Tip

Prior to each measurement triggered with **MEAS** it is possible to enter a point number and a code for the point to be measured. The point number is incremented automatically by 1 without any need to lift a finger.

In the programs, the codes for defined points are invariably set (A, B, C, S) and cannot be changed.

- B** to continue in the program by calling point B
- ESC** to return to the higher-order menu
- A** to repeat point A if required



If A has been calculated, measured or defined as station, the symbol for A (square) is filled. Now, the point B or P can be treated exactly the same way.

Tip

If errors or confusions should occur whilst measuring to the points, the measurement to single points can be repeated immediately.


Applications

Connecting Distance

If it is not possible to measure a distance between two points directly, the measurement to these points has to be started at a station point S. Then, the program calculates the distances SD, HD and the height difference h between the points.

Examples for application:

Measurement of cross sections, checking the distances between points, boundaries and buildings



meas.: : (SD,HZ,V)_{A,Pi}, th

requ.: : (SD,HD,h)_{A-P}, (SD,HD,h)_{P-P}, Z_P

Measurement „Connecting Distance“

CHK



Adjusting and checking

A

to start by calling point A



th

to enter the reflector height of A

ON +

PNo

MEAS

to measure to point A



In measurements with stationing in elevation, the height Z of the point is additionally displayed.


A Measurement to point A to be repeated?

P to call point P

th to enter the reflector height of P

ON + **PNo**

MEAS to measure to point P



Tip

After completing the determination of the first connecting distance, there are two different methods for continuing the measurement:

- polygonal measurement P-P or
- radial measurement A-P.



The method can be changed at any time after returning to the higher-order menu and selecting again.

P-P page 5-7

A-P page 5-8


A to repeat measurement to point A

DSP to change over the different displays of results



Display of results and saving

Polygonal Connecting Distance P - P




The results are always related to the last two points measured.

th to enter the reflector height of the next point P


ON + **PNo**

MEAS to measure to point P




Further points P:

th, **ON** + **PNo**, **MEAS**



Display of results and saving

Radial Connecting Distance A - P



The results are always related to point A.

th to enter the reflector height of the next point P


ON + **PNo**

MEAS to measure to point P




Further points P:

th, **ON** + **PNo**, **MEAS**



Display of results and saving

Recording

 **Presettings**
First steps

If recording is activated, the following lines are saved in dependence on the settings:

Designation of the mode

Point numbers and code

SD, Hz, V Polar coordinates A,P

th, ih Reflector height, instrument height
(only if changed)

SD, HD, h Connecting distance A-P or

SD, HD, Z Connecting distance A-P or

SD, HD, h Connecting distance P-P or


SD, HD, Z Connecting distance P-P

Applications

Object Height

Heights of inaccessible points are determined by measuring SD, V to an accessible point in the plumb line. Only the angle V is measured to the inaccessible point.

Examples for application:
 Determination of tree heights, widths of tree tops and trunk diameters, power lines, passageways and bridge profiles, setting out of heights on vertical objects



meas.: : $(SD, V, th)_A, V_P$

requ.: : $Z, HD, (O)$

Measurement „Object Height“

CHK



Adjusting and checking



A

to start by calling point A

th

to enter the reflector height of A



ON +

PNo

MEAS

to measure to point A

- P** to call point P
- ON** + **PNo**,
- to sight point P
- MEAS** to measure to point P / further points P

Measurement to point P




Display of results and saving

Definition of a Reference Height ZSet

With **ZSet**, a horizon with a given height can be defined.

- ┌ Z 0.000 m
Confirming the old reference height (in this case 0)



- ┌ Principles
First steps

- ON** + **PNo**
- MEAS** to measure to the reference height




Further points:

- ON** + **PNo**, **MEAS**



Display of results and saving

Measurement beside the Plumb Line



Further points:

ON + **PNo**, **MEAS**

to the left of the plumb line

HD	1.215 m	+	P
O	-0.364 m		Z
Z	1.988 m	HD	↓ I
ESC ZSet			


Further points:

ON + **PNo**, **MEAS**

to the right of the plumb line

HD	1.264 m	+	P
O	0.505 m		Z
Z	1.978 m	HD	↓ I
ESC ZSet			

Recording

 Presettings
First steps

If recording is activated, the following lines are saved in dependence on the settings:

Designation of the mode

Point numbers and code

SD, Hz, V Polar coordinates A

Hz, V Measuring point P

HD,O,Z Measuring point P

Z Set value Z


Applications

Station + Offset

Determination of the rectangular coordinates of any point in relation to a reference line defined by the points A and B.

Examples for application:

- Checking of point distances from a reference line,
- checking of boundaries,
- intersection of sight rails,
- determination of the distances of buildings from boundaries, footpaths or streets,
- alignment of long straight lines in the event of visual obstacles on the line,
- surveying of supply lines and channel routes referred to roads and buildings,
- free stationing in a local system



meas.: : $(SD, Hz, V)_{A,B,P}, th$

requ.: : $(x, y, \omega)_P$, referred to line A-B

h_{A-B}, h_{A-P}

Measurement „Station + Offset“

CHCK



Adjusting and checking

A

to start by calling point A




th to enter the reflector height of A

DSP to change over the different displays of results


ON + **PNo**

MEAS to measure to point A

A=S page 5-18



Display of absolute altitude Z (only with stationing in elevation carried out)



Display of height difference h

B to call point B

A Measurement to point A to be repeated?



th to enter the reflector height of B

ON + **PNo**


MEAS to measure to point B

B=S page 5-19



- P** to call point P
- B** B to be repeated?
- A** A to be repeated?

The results refer to points A and B



Display of results and saving

- th** to enter the reflector height of P

ON + **PNo**

- MEAS** to measure to point P

- P=S** page 5-19

- DISP** to change over the different displays of results

- CONS** to enter constants for x and y page 5-20

Measurement to point P



further points P

- th** to enter the reflector height of P

ON + **PNo**

MEAS

The result can now be displayed in three different modes.



Display of results and saving y, x, h

DSP to change over the different displays of results



Display of results and saving x, y, Z

DSP to change over the different displays of results



Display of results and saving x, y, ω

Attention !

If the mode is changed after the measurement, the values will be converted and displayed in the new mode, but saved in this form only after the next measurement.

Tip


Change the mode before the measurement.

The Station equals Point A A = S

L  Principles
First steps

YES to confirm

NO to reject



B to continue in the
main program




Saving

The Station equals Point B B = S

  Principles
First steps


YES to confirm

NO to reject




The results refer to points A and B(S)

P to continue in the main program




Display of results and saving

The Station equals Point P P = S (checking)

  Principles
First steps


YES to confirm

NO to reject



To continue in the main program:


th, **ON** + **PNo**, **MEAS**



Display of results and saving

Shifting the Coordinate Axes y, x

If a line does not begin with the coordinate $x=0,00$, the corresponding value can be entered after having measured the line. If it is a parallel line, the parallel distance y can be entered in the same way. Consequently, the computation is always related to the new and parallel line.



CONS to call the menu for defining axes

The result of a measurement to a point P is displayed as follows:

```

y      0.018m  A---x---B
x      1.365m  |
h      -0.017m  |P
ESC PE CONS th DSP
    
```

Input of shift values for y and x axes

Principles
First steps

Example: $x=5,000$ m

o.k. to confirm input

```

y      0.000m
x      5.000m
ESC o.k.
    
```

The change is recorded

MEAS to measure



Display of result after changing the origin of coordinates

Tip

The input of constants for y and x allows to set out parallel and rectangular lines in an elegant fashion making additional computations superfluous. This applies especially to the intersection of sight rails and setting out of axes.

Recording

 Presettings
First steps

If recording is activated, the following lines are saved in dependence on the settings:

Designation of the mode

Point numbers and code

SD, Hz, V Polar coordinates A,B

th,ih Reflector height, instrument height
 (only if changed)

SD, HD, h Basis A-B

SD, Hz, V Polar coordinates P

y,x,h Coordinates P or

y,x,Z Coordinates P or

y,x, ω Coordinates P and angle ω

A=S, B=S

and P=S Information lines

Y,X,h P=S

y,x constants for y and x


Applications

Vertical Plane

A vertical plane is defined by angle and distance measurements to two points. The coordinates of further points in this plane are determined by an angle measurement only.

Examples for application:

Surveying of building façades, heights of passageways, bridges or motorway signs, determination of coordinates in a vertical plane for the determination of heights and volume computations, setting out of sectional planes (planimetry and height) for façade construction



meas.: : $(SD, H_z, V)_{A,B}$, th , $(H_z, V)_P$

requ.: : $(y, x, h)_P$

Measurement „Vertical Plane“


CHCK



Adjusting and checking

A

to start by calling point A



th

to enter the reflector height of A

ON + **PN0**

MEAS to measure to point A



B to call point B
th to enter the reflector height of B

ON + **PNo**


MEAS to measure to point B



P to call point P

ON + **PNo**

MEAS to measure Hz and V to point P



Display of results and saving

To measure to further points

hSet see below

xSet page 5-25

y page 5-26

P=S page 5-27




Display of results and saving

hSet - Determination of the Height Coordinate

Definition of the horizon:

L h 0.000 m
 Confirm the old reference height (in this case 0)

L Principles
 First steps



Input $h=1,00\text{m}$

ON + **PNo**

MEAS to measure Hz and V to point P



The results refer to the new height

To measure further points




Display of results and saving

xSet - Definition of the x - Axis

L x 0.000 m
Confirm the old reference height (in this case 0)

L Principles
First steps



Input $x=1,00\text{m}$

ON + **PNo**

MEAS to measure Hz and V to the desired point P



The results refer to the new x - axis
(in this case, the desired and set zero point of
coordinates has been measured)

To measure further points




Display of results and saving


y - Points in front or behind the Plane

Definition of preceding sign

o.k. to confirm



L y 0.000 m
Confirm the old
value
(in this case 0)



L y = 0
Set to zero

L Principles
First steps

After entering y=0,350m:

ON + **PNo**

MEAS to measure Hz and
V to point P




Display of results and recording

The Station equals Point P P=S

L  Principles
First steps


YES to confirm

NO to reject



Coordinates of S with reference to plane A-B

ESC further points



Display of results and recording

Recording

 Presettings
First steps

If recording is activated, the following lines are saved in dependence on the settings:

Designation of the mode

Point numbers and code

SD, Hz, V Polar coordinates A,B

th,ih Reflector height, instrument height
(only if changed)

SD, HD, h Basis

Hz,V P

y, x, h P

P=S Information lines


Y,X,h P=S

Applications

Area calculation

Area calculation by measurement to the corner points **or** input of the corner point coordinates of the area or calling them from the memory. A direct combination of both methods is impossible (see page 5-29).

The area is limited by straight lines. Any number of corner points can be used.



meas.: : (SD,HZ,V)_{A,B,C,Pi}

or given.: : (y,x)_{A,Pi} (Y,X)_{A,Pi}

comp.: : Fl (A-B-C-Pi)

Range:

$0,01\text{m}^2 \pm 0,01\text{m}^2 < Fl < 90\ 000\ 000\text{m}^2 + 1\text{m}^2$

Measurement „Area Calculation“


PRUE



Adjusting and checking


A

to start by calling point A



⚠ Attention !

The points of the area are to be measured, called from the memory or entered in proper order. In each case, the last point can be repeated. It is not possible to insert a forgotten point subsequently.



Tip!

If not all points can be seen from one station, the following procedure is recommendable:

Divide the corner points into groups so that all corner points can be seen from two or more stations.

1st corner point group

Determination of corner point coordinates of the area by means of

- stationing in a local or global network and
 - polar measurement of the 1st group
- Coordinates of these points are now stored in the instrument memory

2nd corner point group

Move the instrument to another place from where the remaining points of the area can be seen.

- stationing in a local or global network (as for the 1st group) and measurement of the remaining points
- all points are now stored in the memory

Starting the area calculation



- Call the corner points of the area from the memory considering the order

This method works only in case of instruments with internal memory. The Trimble 3306DR allows to measure the points only. It is possible, however, to calculate an area (F) to be covered through various stations. The subareas (F1 + F2) are arranged in such a way that they can be assembled to a total area. A stationing is not necessary for this purpose.

$$F = F1 + F2$$

MEAS to measure to point A or

YX Input or select memory coordinates of point A

L  Principles
 First steps
 Editor
 Data management



Input coordinates



The operational steps for point B and C are now carried out in analogy to point A.

After measuring to A,B and C, the area is calculated for the first time:

ESC to quit the program

C to repeat measurement to point C

P to continue in the program by calling point P_i

o.k. to quit the area calculation and store the result




Rept to repeat the last point P_i

P to continue in the program by calling point P_{i+1}

o.k. to quit the area calculation and store the result


Display of result after measuring to another point P_i :



Tip!

Any number of corner points can be used.

Recording

 Presettings
First steps

If recording is activated, the following lines are saved in dependence on the settings:

Designation of the mode

Point numbers and code

y,x or

Y,X Coordinates of points A, B, C, P_i

SD,HZ,V Reading of points A, B, C, P_i

Fl Area

Decisive features of an efficient work routine are the saving of the measured and computed values as well as the transfer of measured data to a PC and the transfer of coordinates from the PC to the surveying instrument. This chapter describes all processes necessary to meet these requirements. The section *Editor* only applies to Trimble 3303DR and Trimble 3305DR.

Editor	6-2
--------	-----

Data Transfer	6-8
---------------	-----

Data Formats	6-15
--------------	------

User Interface	6-38
----------------	------

Remote Control	6-40
----------------	------

Recording Data Lines	6-63
----------------------	------

Update	6-70
--------	------

Calling the EDIT Menu

ON EDIT



Compensator activated

Indication of battery level

Display of the free data lines and address of the last data line written

Display of Data Lines

Disp to go to memory display


? to call search function

↔ to change page

↑ to display preceding data line

↓ to display following data line

ON PNo allows to change point number and code



Attention !

In the coordinate and application programs, fixed codes are assigned to certain data lines. Such codes can not be modified by the operator.


Searching for Data Lines

? to call search function

?P to search for point number

?C to search for point code

?A to search for address



Input of the point number, code or address to be searched for

?↓ to continue search using the same criterion

↔ to change page

↑ to display preceding data line

↓ to display following data line

ESC to quit search routine



Tip

If no data line is found to which the search criterion applies, search is followed by an error message.

Deleting Data Lines

Del to call the function "Delete"



🔗 Technical Information

This function deletes all data lines or the data lines from a selected line number (address) to the last data line saved.

🔗 Attention !


The deletion is definite and irrevocable. To avoid any unintentional loss of data, most care has to be taken over this action!

all to select all lines

?P or from the line with point number xx

?C or from the line with code xx

?A or from the line with address xx



Example: search for point number 2


?↓ to continue search using the same criterion



↔ to switch over to the page of readings




o.k. to confirm the line



For another check, the selected data lines are displayed again and have to be confirmed.

YES to confirm the selection

NO to reject the selection / quit the routine



Entering Data Lines

Inpt to call the function "Input"



YX to enter the planimetric coordinates




YXZ to enter planimetric coordinates and heights

Z to enter heights

Example of a height input:


L Z 149,362 m
Confirmation of the old value (in this case 149,362 m)




L Z = 0
Set the height to zero


L input
 Principles
First steps


 and



 to go to the desired position


 and


 to browse through digits

 to confirm

 to switch over to the page for readings


  to enter point number and code

 to confirm and save




Input of further coordinates and heights with point number and code



 Presettings
First steps

Attention !
The sequence and designation of the coordinate axes depend on the selected system of coordinates and the setting of the display of coordinates. The softkey YX and YXZ, respectively, is labelled according to this selection.

Introduction



Data transfer can be performed between **Trimble 3300DR** and **PC** by **cable**



This allows an easy data exchange between instrument and computer.

Preparation on the Instrument

ON + MENU

6 Interface

YES to go to the menu

MOD to change settings

Trimble 3300DR ↔ PC
Connect both devices by the serial interface cable and start the necessary programs for data transfer.

Cable for data transfer
Trimble 3300DR ↔ PC with protocol Xon/Xoff:

Order number
708177-9470.000

Main menu.

Menu Interface Trimble 3300DR



Interface parameters for transmitting and receiving project files:

Data format: R4, R5, Rec500 or M5

Baud rate: 9600

Parity: even

Protocol: Xon/Xoff

Stop bits: 1 (not variable)

Data bits: 7 (not variable)

Tip


For data transfer to and from the PC, you can use for example the MS-Windows™ 98 Hyperterminal program.

Preparation on the PC - Hyperterminal Settings

Set the PC for data transfer as follows:


Step 1

Example for Windows™ 98
Hyperterminal program:



Settings:Connect using – Com port

Step2



Settings:Function, ... – Treminal keys


Backspace .. – Ctrl H

Emulation ... – Auto detect

Telnet term. – ANSI


Backscroll ... - 500

Step 3




Step 4:

For sending or receiving a project file, select "Transfer" as shown below:



Step 5:

To transmit a project file, select “Send text file” or “Receive text file”.



Tip

The format of the transmitted file is *.txt. For using the file with Trimble sensors, controllers or office software packages like TTC, TGO or TM the format *.dat is required. Therefore the file has to be renamed.

Data Transmission

ON + MENU

6 Interface

YES to go to the menu


1 MEM ----> Periphery

YES to confirm


Main menu:

Scroll until submenu Interface

Data transfer menu between Trimble 3300DR and PC.



Selection of the required data lines




Editor Data Management

Tip


Now, set the PC to „Receive text file“. The instrument or program at the receiving end must be set to the receive mode before you can transmit the project file.

YES to start



The data lines are transferred to the PC.

ESC to end data transfer



Data Reception

ON + MENU

6 Interface

YES to go to the menu


2 Periphery -----> MEM

YES to confirm


Main menu:

Scroll until submenu Interface

Data transfer menu between PC and Trimble 3300DR.




Enter the name of the source file into the PC Start the transfer from the PC



The data lines are transferred to the Trimble 3300DR.

Attention ! The instrument only accepts coordinates.

ESC to end data reception



Tip Time Out occurs after 30 seconds without data communication. The message „Time Out“ indicates a data error. After that, the program returns to the data transfer menu.

Introduction


Trimble surveying instruments are used for measurement functions with different data processing requirements.


The Trimble 3300DR series allow densely packed internal measurement and result data lines to be output in various formats.

M5, R4, R5, Rec500 record format

Four data formats which have grown historically are subject to on-site revision service for compatibility with customer instruments. Currently, M5 is the format to provide most comprehensiveness in definitions. It should be used preferentially for any other tasks.

This chapter describes the structure of data format and the type identifier of measured and calculated values.

 Data transfer
Data management

 User interface
Data management

Technical

All instruments have a serial interface which ensures the data exchange.

Attention!

Instead of the usual marks within the 27 digit point identification, the M5 data format of Trimble 3300DR is limited to a 12 digit point number and a 5 digit code.

Description of M5 data format

„M5“ -> 5 Measuring data blocks per data line:

- 1 Address block
- 1 Information block
- 3 numerical data blocks

The original Zeiss M5 data format is the common standard for all former Elta® surveying systems and current Trimble 3000 systems

All 5 data blocks are preceded by a type identifier. The 3 numerical data blocks have a standard layout comprising 14 digits. In addition to the decimal point and sign, they accept numeric values with the specified number of decimal places.

The information block is defined by 27 characters. It is used for point identification (PI) and text information (TI e.g.).

The address block is comprised of 5 digits (from address 1 to 99999).

The M5 data line

The data line of the M5 format consists of 121 characters (bytes). The multiplication of this figure by the number of addresses (lines) stored shows the size of the project file in bytes.

Blanks are significant characters in the M5 file and must not be deleted.

The example describes an M5 data line at address 176 with coordinates (XYZ) recorded in unit **m**. The point identification of marking 1 is **DDKS S402 4201**. Column 119 includes a blank (no error code).

The end of the line has CR, LF (columns 120 and 121, shown here as <=).

Explanations to the data line

Abbr.	Description	Digits	Characters	Meaning
For M5	Format identifier Format type	3	alpha	Trimble 3300DR Format
			2	alpha
		meas. data blocks		5
Adr	Address identifier Value1	3	alpha	Value1
		5	numeric	Memory address
T2	Type identifier	2	alpha	Value2 (Pla ,TI, TO...)
a	Marking Value2	1	numeric	a=1, 2, 3 ,..., 9, 0
		27	alpha	PI or TI
T3	Type identifier	2	alpha	Value3
	Value3	14	numeric	14-digit value
dim3	Unit	4	alpha	4-digit unit
T4	Type identifier	2	alpha	Value4
	Value4	14	numeric	14-digit value
dim4	Unit	4	alpha	4-digit unit
T5	Type identifier	2	alpha	Value5
	Value5	14	numeric	14-digit value
dim5	Unit	4	alpha	4-digit unit
?	Identifier	1	alpha	Error message, or ■
Special characters			ASCII code	Hex code
	Separator	1	ASCII 124	Hex 7C
■	Blank	1	ASCII 32	Hex 20
<	CR (Carriage Return)	1	ASCII 13	Hex 0D
=	LF (Line Feed)	1	ASCII 10	Hex 0A

Additional data lines of M5 data format–Header/changed setting

For M5\Adr 0000\1\TI START	I01	3305	I02	9000005	I03	562
For M5\Adr 0000\2\TI	I04	30	I06	1		
For M5\Adr 0000\3\TI	I05	1	I21	11	22	16
For M5\Adr 0000\4\TI	Ith	1,900 m	Ic	1,600 m	ISZ	0.0060 grd
For M5\Adr 0000\5\TI	Ii	0.0005 grd	IP	0.0025 grd	IPC	0.035 m
For M5\Adr 0000\6\TI	IT_	20 C		1012 hPa		
For M5\Adr 0000\7\TI	Im	1.0000000				
For M5\Adr 0000\8\TI END						

The additional M5 data lines are implemented to optimize the datatransfer (Import / Export) from and to the Trimble office software like TTC, TGO and TM.

Tip: Beginning with software version >5.61 the additional data lines are implemented in the M5 data format.

Header

The Header is recorded after switch ON the instrument and begins with START and end up with END.

The new identifier in the M5 Format - Header

Abbr.	Description	Digits	Characters
01	Type instrument	2	numeric
02	# instrument	6	numeric
03	Version software	3	numeric
04*	Language	2	numeric
05	Coord. System	1	numeric
06	Oder Coord.Syst	1	numeric
20	Position I	1	numeric
21	Position C	2	numeric
22	Position P	2	numeric

* Each language is coded with two numbers (see next page)!

Coding of languages

Code	Language
23	German
30	English
31	Czech
32	Italian
33	Croatian
34	French
35	Dutch
36	Spanish
37	Danish
38	Polish
39	Hungarian
40	Japanese
41	Turkish
42	Russian
43	Finnish
44	Estonian
45	Portuguese

Content of the Header
Explanation of the example
page 6-19

Abbr.	Description	Meaning of Example
01	Type instrument	Trimble 3305DR
02	# instrument	900005A
03	Version software	6.82
04	Language	30 / English
05	Coord. System	xy
06	Order Coord.Syst.	yx
20	Position I	Start position 1
21	Position C	Start position 11
22	Position P	Start position 16
th	Target height	1,90m
ih	Instrument height	1,60m
i	Vertical index cor.	-0,0005 grd
c	Sighting axis cor.	0,0025 grd
SZ	Run Center comp.	0,0060 grd
T	Temperature	20°C
P	Air Pressure	1012 hPa
PC	Prism constant	-0,035m
M	Scale	1,000000

Changed settings

Record changed settings of
the instrument

Changed settings of the instrument are recorded permanent while the instrument is in operation. The menu „Record Settings“ has to be activated (see pages 3-27, 3-28).

For M5 Adr 00009 TI	INPUT	ih	2.000 m	ih	1.700 ml	0.0055 grd
For M5 Adr 00010 TI	ADJUST	IV1	92.4505 grd	IV1	ISZ	-0.0010 grd
For M5 Adr 00011 TI	ADJUST	Hz	284.1015 grd	Hz	li	0.0025 grd
For M5 Adr 00012 TI	ADJUST	Hz		Hz	lc	0.0055 grd
For M5 Adr 00013 TI	ADJUST	P	25 C	P	ISZ	-0.005 m
For M5 Adr 00014 TI	INPUT	IT_	1.000005	IT_	IPC	
For M5 Adr 00015 TI	INPUT	Im				
For M5 Adr 00016 TI	COM-OFF					
For M5 Adr 00017 TI	COM-ON					
For M5 Adr 00018 TI	Hz=0	Hz		Hz		0.0000 grd
For M5 Adr 00019 TI	HOLD	Hz		Hz		300.0000 grd
For M5 Adr 00020 TI	DR	PC	0.000 m	PC	A	0.000 m
For M5 Adr 00021 TI	PR	PC	2.000 m	PC	A	0.030 m
For M5 Adr 00024 TI	KN STAT	Hz	1000.000 m	Hz	IV1	92.4435 grd
For M5 Adr 00025 TI		X		X	IZ	0.000 m
For M5 Adr 00026 PI1		IOm		IOm		
For M5 Adr 00027 TI		S				

Record changed settings

The following changed settings and adjustments are recorded while the instrument is ON:

Record	T1	T2	T3	Comment
INPUT	th	ih	-	input th/ih
ADJUST	V1(1)	V1(2)	i	adjustment V-Index/Collim.
ADJUST	Hz(1)	Hz(2)	c	adjustment V-Index/Collim.
ADJUST	-	-	SZ	adjustment V-Index/Collim. or Compensat.
INPUT	T_	P	PC	Input Temp., Air Pressure, Prism constant
INPUT	m	-	-	Input scale
COM-ON-	-	-	-	Compensator switched ON
COM-OFF-	-	-	-	Compensator switched OFF
Hz=0	-	Hz(=0)	-	Hz set to 0
HOLD	-	Hz	-	Hz set to desired angle
DR*	-	PC	A	DR mode switched ON
PR**	-	PC	A	PR mode switched ON

* PC=0, A=0
 ** PC=set, A=calculated

For your information only!
Trimble 3300DR -
Page 6-17

The point identification PI in M5 Format

The PI is comprised of 27 characters. It starts in column 22 and terminates in column 48 in the M5 data line. The data structure within the PI is defined by markings. A maximum of 10 markings, marked in the preceding type identifier with PI1 to PI0 (columns 18, 19, 20), can be designated to the PI (depending on the instrument).

For your information only!
Trimble 3300DR -
page 6-32

The type identifier in the M5 Format

In the course of the time, requirements on the data format have increased. Therefore, the M5 Format carries most of the type identifiers of all available formats, always based on the preceding format (Rec500).

Type identifiers are defined by two characters (except for **Adr**). If only one character is necessary, the second character is a blank.

In the M5 Format there are 5 Type identifiers (TK) defined:

TK1:	Adr	Identifier address (Value1)
TK2:	T2	Identifier information (Value2)
TK3:	T3	Identifier 3. Value field (Value3)
TK4:	T4	Identifier 4. Value field (Value4)
TK5:	T5	Identifier 5. Value field (Value5)

Example:

„PI“ for point identification or „TI“ for text information can be used for T2. For T3, T4, T5, „D“, „Hz“, „V“ or „Y“, „X“, „Z“ can be used.

Description of Rec 500 data format

„Rec500“ stands for the description of the electronic field book Rec500.

With the electronic field book **Rec500** a data format was developed which was created for Trimble / CZ instruments years ago and is today the base for the M5 format..

- 1 Address block
- 1 Block Information
- 3 Numeric data blocks

The Rec500 format is divided in 5 marking blocks (analogous the M5 format). These blocks differ in their block length from the M5 format, 80 characters (Bytes) are available on a data line.

The Rec500 Data line

The data line in the Rec500 format is comprised of 80 characters (Bytes).

Abbr.	Description	Digits	Characters	Meaning (w. example)
W1	Address	4	numeric	Memory address
PI	Point identification	27	num / alpha	Point identification (14-digits) and additional information (13 digits)
T1	Type identifier 1. Value	2	num / alpha	D = slope distance E = horizontal distance Y = coordinate, etc.
		12	numeric	
T2	Type identifier 2. Value	2	num / alpha	Hz=horizontal direction X = coordinate, etc.
		13	numeric	
T3	Type identifier 3. Value	2	num / alpha	V1=zenith angle Z = coordinate, etc.
		9	numeric	

Special characters

			ASCII code	Hex code
■	Blank	1	ASCII 32	Hex 20
<	CR (Carriage Return)	1	ASCII 13	Hex 0D
=	LF (Line Feed)	1	ASCII 10	Hex 0A

Description of R4 and R5 (M5, Rec 500) format of Trimble 3300DR

„R4“ stands for the data recording format of the Trimble 3300DR instruments containing 4 measuring data blocks:

- 1 Information
- 3 numeric Data blocks

„R5“ stands for the data recording format of the Trimble 3300DR instruments containing 5 measuring data blocks:

- 1 Address block
- 1 Information block
- 3 numeric Data blocks

Two data recording formats - R4 and R5 - are available in the Trimble 3300DR total stations. Both formats can be chosen in the instruments. Depending on the setting with or without address, either data record format R5 (with address) or R4 (without address) can be used.


R4 and R5 format data lines

The data line in the R4 format contains 80 characters (Bytes). It is comprised of an information block and 3 numeric value blocks.

The data line in the R5 format contains 89 characters (Bytes). It is comprised of one address block, one information block, 3 numeric value blocks.

Both formats contain the same type identifiers for each block..

Abbr.	Description	Digits	Characters	Meaning
For R4 , R5	Marking format format type R4, R5	3 2	alpha alpha	Trimble 3300DR Format 4 or. 5 Data blocks
Adr <aa>	Address marking Value1	3 4	alpha numeric	3 digits for marking Address in R5 Format
Tk <Info>	Type identifier Info Info	2 7	alpha num / alpha	Type identifier TR or KR Info for data line
Ti i <Wi>	Type identifier Value Value i (i = 1,2,3)	2 11	num / alpha numeric	Type ID Value block Value block Value i
dimi	dim i (i = 1,2,3)	4	alpha	Unit block Value i

 **Special characters
M5 Data format**

The special characters ■, |, < and = are analogous the M5 format.

Lineal	1234567890123456789012345678901234567890123456789012345678901234567890
Belegung	▶ For R4 Tk • 1234567 T1 • 12345678901 • dim1 T2 • 12345678901 • dim2 T3 • 12345678901 • dim3 <=
Beispiele	▶ For R4 TR EINGABE th <- Info > <- Wert 1 - - - > 0.000 m ih 1.650 m Z 512.358 m <=
	▶ For R4 12.323 m Hz 399.9710 m V1 112.4458 m <=

The R4 Data line

Column 79-80: Carriage Return <, Line Feed =

Column 74-77: Unit for 3. Value block

Column 62-72: 3. Value block

Column 59-60: Type identifier for 3. Value block

Column 54-57: Unit for 2. Value block

Column 42-52: 2. Value block

Column 39-40: Type identifier for 2. Value block

Column 34-37: Unit for 1. Value block

Column 22-32: 1. Value block

Column 19-20: Type identifier for 1. Value block

Column 11-17: Data line information (alpha numeric)

Column 8-9: Type identifier information

Column 1-6: Defines R4 format

■ Blank | Separator

The point identification in the R4/R5 Format

For a point identification in the R4 and R5 format are max. 7 digits available.

The PI is controlled by two Type identifiers, TR and KR, which describe the kind of PI.

TR Type identifier for a text information block

KR Type identifier for a PI with code and point number.

Point number: 0...9, right-aligned, 4-digit

Point code: 0...9, Blank, # 3-digit

The 3 digit code can be combined with additional characters. It is suggested to use the character # for marking incorrect measurements.

Trimble 3300DR - Marking in the M5 / Rec 500 Format

The Trimble 3300DR uses a mark which is saved internal in the instrument. This mark consists of 3 blocks with clearly defined block lengths. The user can manipulate the order of the 3 blocks. Examples:

Layout gage: 1 10 20 27
123456789012345678901234567

Sample Marking: **PPPPPPPPPPP CCCCC IIIIIII**

Sample Marking: **IIIIIII CCCCCPPPPPPPPPPP**

Meaning:

PPPPPPPPPPP 12-digit point number

CCCCC 5-digit point code

IIIIIII 7-digit information block

☞ Tip

The information block (I) is left-aligned, the code (C) and point number (P) are right-aligned.

Upon data conversion to the R4 / R5 format, the point number and point code will be shortened to 5 and 3 digits, respectively. The right-aligned digits remain.

Change settings of Trimble 3300DR –
Markings in the M5 / Rec 500 format

ON + MENU

6 Interface

YES go to the menu

MOD to change setting

↑	5	Position C	11
↔		Position P	1↔
↓	7	Position I	1
ESC	↑	↓	MOD

☞ Tip

In case of overlapping information in the blocs, the instrument returns into its initial settings (default).

Trimble 3300DR –Markings in R4/R5 format

In instruments of the Trimble 3300DR series one marking can be used.

In both the R4 and R5 format 7 characters are available for point identification and marking.

The PI is controlled by two type identifiers TR and KR, which mark the kind of the PI.

TR Type identifier for one text information block

KR Type identifier for a PI with code and point number.

Point number: 0...9, right-aligned, 4-digit

Point code: 0...9, Blank, # 3-digit

The 3 digits in the code can be combined with any applicable character. It is suggested, to use the character # to mark incorrect measurements.

Examples:

Layout gage: **TI 1234567**

Text information: **TR IIIIIIII**

Point number and code: **KR CCCPPPP**

Meaning:

IIIIIII 7-digit Text information block

CCC 3-digit Code block

PPPP 4-digit Point number block

In the M5 / Rec500 Format a 5-digit code and a 12-digit point number are used. In the R4 / R5 Format the established digits (3 and 4, respectively) remain right-aligned.

Definition of type identification

Definition

Type identifiers are assigned to the 5 measuring data blocks of pre-set codes, which show the number or character value of the block.

Type ID 's are defined with two characters.

Type identifiers are (except for **Adr**) defined with two characters. If only one character is necessary, the second character is blank. The code is case sensitive.

The following table lists all Type identifiers in alphabetical order according to the TR/CZ Data Formats and the possible position of characters after the comma (,????) as well as signs (\pm):

Type identifiers - CZ Formats M5,R4,R5,Rec500 (Trimble 3300DR)

Type identifier	,????	\pm	Meaning
A	2,3,4		Distance addition constant
a	6		Horizontal angle of orthogonal line
Adr	-		Address (the only TK with 3 characters)
B			V-angle of control point
c	3,4,5		Collimation correction
c_			Sighting axis error
dl	2,3,4		Longitudinal deviation
dq	2,3,4,5		Transverse deviation
dr	2,3,4		Radial deviation in setting out
dx	2,3,4		Coordinate Difference /Deviation in X direction
dy	2,3,4		Coordinate Difference /Deviation in Y direction
dz	2,3,4		Coordinate Difference /Deviation in Z direction
HD	2,3		Horizontal distance
HV	3,4,5		Hz rotation
Hz	3,4,5	\pm	Horizontal direction

Type identifier	,????	±	Meaning
h	2,3,4	±	Height difference of a station
i	3,4,5		Index correction
ih	2,3,4		Instrument height
KR			Information Trimble 3300DR with code and point number
m	6		Scale
NZ	3,4,5		Compensator reading, sighting direction
O	2,3,4		Transverse distance (indirect height determination)
Om	3,4,5		Orientation (stationing) Omega
P	0,0,1		Air pressure (in hPa, Torr or InMerc)
PI			Point Identification (general)
pa	2,3,4		Parallel distance in 3-D plane
SD	2,3		Slope distance
SZ	3,4,5		Compensator run center: component in line of sight direction
T			Text ID in Rec500 Format
Tv	2,3,4		Type of target eccentricity
Th	2,3,4		Type of target eccentricity
TI	2,3,4		Type of target eccentricity
Tr	2,3,4		Type of target eccentricity
Ts	2,3,4		Type of target eccentricity
TI	-		Text information line
TR			Information Trimble 3300DR as text information
T_	-		Temperature (in °C or °F)
th	2,3,4		Reflector height
V1	3,4,5		Vertical angle: zenith angle
V2	3,4,5		Vertical angle: vertical angle

Data Management

Data Formats

V3	3,4,5	Vertical angle: height angle
V4	3,4,5	Vertical angle: slope in [%]
vy	2,3,4	backsight point residuals
vx	2,3,4	backsight point residuals
vz	2,3,4	backsight point residuals
X	2,3,4	X - Coordinate
x	2,3,4	x - Coordinate (lokal)
y	2,3,4	y - Coordinate (lokal)
Y	2,3,4	Y - Coordinate
y	2,3,4	y - Coordinate (lokal)
Z	2,3,4	Z - Coordinate (Height above MSL)

Description Value blocks

3 Value blocks

In each of the Trimble Elta® formats three value blocks are available whose number of digits depends on the format:

Format	Value1	Value2	Value3	dim
M5	14	14	14	4
R4/R5	11	11	11	4
Rec500	12	13	9	-



Type identifiers

All value blocks are preceded by a type identifier which specifies the function of the succeeding value.

In the M5 and R4 / R5 Format for the value block exists a unit (dim), which follows , 4-digit (divided by a Blank), the value block.

The values are typed right-aligned in the blocks. Decimal point, digits after the comma and definitions of preceding characters correspond to the internal instrument specifications.

⚠ Caution!

If the files of the Trimble Elta® Formats are entered manually, it is important to remember that upon using the data in the instrument the digits after the comma and the units need to be adjusted correspondingly.

The following units are defined:

Angle measurement

gon, DEG, DMS, mil, grad, %

Distances, Coordinates

m, ft

Pressure

Torr, hPa, inHg

Temperature

C, F

Standard, PR etc.

no unit

Trimble Elta® Format ID and address block

Trimble Elta® Format ID in Columns 1-6

In the formats M5, R4 and R5 a marking which corresponds to the format precedes the data line.

For M5 Format marking for M5 Format

For R4 Format marking for R4 Format

For R5 Format marking for R5 Format

„For“ and the marking M5, R4 or R5 are divided by a Blank (ASCII 32).

An exception is the M5 Format for the former GePoS® receiver:

For_M5 Format marking M5 Format for former GePoS® receiver of software versions less than V3.7:

In this case, „For“ and the marking M5 is divided by a „_“ (ASCII 95).

From V3.7 on, the Format marking is **For M5**.

Address blocks

The Formats M5, Rec500 and R5 have an address block which marks the data line with the current memory address. In the M5 and R5 format, a type identifier Adr is activated:

Format	TK	Column	Digit
M5	Adr	12 - 16	5
R5	Adr	12 - 15	4
Rec500	none	4 - 7	4

Adr 00001 or
Adr 1 is allowed.

The address entry is right-aligned. Zeros can be used but are usually omitted. The first data line starts with the memory address 1.

Data output on a printer

Direct data output from the instrument to the printer or from the PC:

The R4 data recording format ensures problem-free printout on A4 printers, with each print line comprising one data line. To achieve the same with the R5 data recording format, the following should be noted:

- Direct data transmission to a printer:
Select condensed font in the printer
or use A 3 printer

- Printing data from a DOS editor:
Select condensed font in the printer
or use A 3 printer

- Printing from a WINDOWS task:
Do not use true type font or proportionally spaced font, but e.g. Courier
Select a small type size
Use landscape print format

⚠ Attention!

For printing of data lines from the instrument at a printer is a serial type of printer interface necessary.

Introduction

This chapter describes the conditions of data transfer, the pin assignment of the interface and key codes and function requests for controlling the instrument by a computer.

What is an Interface?

An interface is the point of contact between two systems or system areas, i.e. the point where information is interchanged. To ensure that it is understood by both the transmitting and receiving unit, specific rules must be defined for the transmission of signals and data.

Hardware interface

This is a physical connection between functional units such as measuring instruments, computers or printers.

Of significance for the user are:

- shape and pin assignment of the connectors on the functional units and connecting cables
- The data transmission method. The parameters and protocols for transmission control

Software interface


Software interfaces establish the link between programs or program modules. The data to be transmitted must conform to a defined structure: "The record format".

User interface

This is also called user guidance, important for handling of a system.

Interfaces between the user and the system are the monitor, the keyboard and the options for user guidance provided by the software. In the Trimble 3300DR concept, special emphasis has been placed on the design of the user interface.

Hardware interface



The interface for the peripheral equipment is of the asynchronous, serial type and conforms to DIN 66020 standard (V 24 / RS 232 C).

The interface is provided on the slip ring connection.

Interface functions:


(1) Data transfer:

Direct transmission of measured data between Trimble 3300DR and the connected peripheral instrument (computer, printer,...).

A series of transmission parameters are available for the control of this process.

(2) Software updates for the Trimble 3300DR can be loaded via this interface .

Pin assignment of the interface /connecting cable



Pin assignment (exterior view of connector), 8-pin female stereo connector

Pin	Signal	Direction	Designation
1	-	-	
2	Ground	-	Ground (-U _{batt})
3	-	-	
4	SD	Output	Transmitted data
5	ED	Input	Received data
6	Vcc	In	External power supply (+U _{batt})
7	Vcc	In	External power supply (+U _{batt})
8	Ground	-	Ground (-U _{batt})

Connecting cables:


Cable 7081779460000 is used for external data recording/remote control (e.g. Map500) and for data transfer to a PC. You can also use cable 7081779470000 (with angled plug) if the Trimble 3300DR is installed on a tripod during data transfer.

For remote control from TSC1/TSCe use cable 7081809001000.

Introduction


This chapter describes the conditions of data transfer, data transmission protocols, overview about key codes and answers of the PC for the instrument control.

XON/XOFF Control



The XON/XOFF protocol is a very simple, but efficient data transmission protocol. It is preferably employed for so-called terminal programs (e.g. Hyperterminal under Windows or Xtalk) and can be used in data recording from the Trimble 3300DR to a computer.

Rec 500 Software Dialog (Rec 500 Protocol)



Control diagram of the "Rec 500 software dialog"

The following definitions apply to the time values entered in the control diagram:

t_1 : Interval between signal A from Trimble 3300DR and the response from the recording unit with signal B, and interval between the end of data transfer and the acknowledgement with signal B.

$$0 > t_1 < t_{(\text{Time-Out})} \quad t_1 = 20 \text{ s}$$

The recording unit may respond without delay to the recording request from the Trimble 3300DR. However, the selected time-out $t_{(\text{Time-out})}$ must not be exceeded; otherwise an error message is displayed and external recording is deactivated. The Trimble 3300DR assumes that no external recording unit has been connected.

t_2 : Interval between the acknowledgement of the reception of a data line by the connected recording unit with signal B and the transmission of a further data line. Depending on the type of recording line involved, this amounts to

$$10 \text{ ms} > t_2 < 100 \text{ ms}$$

Rec 500 software dialog is also suited for data transmission to the Trimble 3300DR. The control diagram is identical to the one shown above, with the designations of the transmitted data line and received data line being interchanged, as data is now transmitted by the peripheral unit.

Key Codes and Function Requests

If the Trimble 3300DR is controlled by a computer or external data logger / controller, the keys can be emulated with the following codes:

Key Codes:

Key	Code	Key	Code
F1	T31↵	ON+F1	TB1↵
F2	T32↵	ON+F2	TB2↵
F3	T33↵	ON+F3	TB3↵
F4	T34↵	ON+F4	TB4↵
F5	T35↵	ON+F5	TB5↵
MEAS	T4D↵	ON+MEAS	TCD↵

↵ symbol for CR/LF

The Trimble 3300DR can be controlled either by key pressure or, equally, from a connected computer. Each recognized key code is acknowledged by the Trimble 3300DR with 'Q↵'; in the event of errors such as incorrect syntax of the call or data transmission errors, the response is 'E↵'.

Function requests: _____

Each function request is answered with a data line in the selected format. The with/without address setting (format setting) is effective. Only the XON/XOFF protocol is used.

Code	Meaning
FKO↓	Compensator reading in sighting direction
FMD↓	Slope distance SD
FMW↓	Angle readings Hz, V
FMS↓	SD, Hz, V
FMR↓	HD, Hz, h reduction
FMK↓	y, x, h local coordinates
FLO↓	Laser Pointer OFF
FL1↓	Laser Pointer ON
FPL↓	Prismen mode (Standard Range – default)
FPH↓	Prismen mode (Long Range)
FDR↓	Direct reflex mode

⚠ Attention!

The values entered for scale, addition constant, index and collimation correction are taken into account in all function requests.

Parameters:

```
Reading:      ?KTTT↵
Response:    !KTTTΔΔ|1234567890123456Δunit↵
Setting:     !KTTTΔΔ|12345678901234Δunit↵
Response:    Q↵
```

The response to a reading command is identical with the setting command.
In the event of errors such as incorrect syntax of the call or data transmission errors, the response is 'E↵'.

Designations:

- ?K fixed character string for reading
- !K fixed character string for setting
- TTT type identifier (see examples)
- ↵ carriage return/line feed
- | separator, ASCII dec. 124
- 1-6 numerical value, 16 characters
- Δ blank, ASCII dec. 32
- unit unit of the associated numerical value,
 4 characters or blanks
- Q Acknowledgement


```
?KSMT_ J Temperature Resolution and Unit RW
!KSMT_ |AAAAAAAAAAAAAAAAA1C_ (1 C/1 F)

?KSMD_ J Pressure Resolution and Unit RW
!KSMD_ |AAAAAAAAAAAAAAAAA1hPa_ (1 hPa/1 Torr/0.1 inHg)

?KSZ_ J Compensator Run Center in Sighting Direction RW
!KSZ_ |AAAAAAAAA0.00000_

?KBz_ J Compensator Reading in Sighting Direction RO
!KBz_ |AAAAAAAAA0.00000_

?Ki_ J Index Correction RW
!Ki_ |AAAAAAAAA0.00000_

?Kc_ J Collimation Correction RW
!Kc_ |AAAAAAAAA0.00000_

?KHV_ J Hz Rotational Angle RW
!KHV_ |AAAAAAAAA0.00000_

?KA_ J Addition Constant RW
!KA_ |AAAAAAAAA0.000_

?Km_ J Scale RW
!Km_ |AAAAAAAAA1.00000_

?KP_ J Air Pressure RW
!KP_ |AAAAAAAAAAAAAAAA944hPa_

?KT_ J Temperature RW
!KT_ |AAAAAAAAAAAAAAAAA20C_

?Kih_ J Instrument Height RW
!Kih_ |AAAAAAAAA0.0000_

?Kth_ J Reflector Height RW
!Kth_ |AAAAAAAAA0.0000_

?KY_ J Y Coordinate of the Station RW
!KY_ |AAAAAAAAA0.0000_
```

Δ - blank

```
?KXΔSΔ↓ X Coordinate of the Station RW
!KXΔSΔΔ|ΔΔΔΔΔΔΔΔΔΔΔ0.0000ΔmΔΔΔΔ↓

?KN.SΔ↓ N Coordinate of the Station RW
!KN.SΔΔ|ΔΔΔΔΔΔΔΔΔΔΔ0.0000ΔmΔΔΔΔ↓

?KE.SΔ↓ E Coordinate of the Station RW
!KE.SΔΔ|ΔΔΔΔΔΔΔΔΔΔΔ0.0000ΔmΔΔΔΔ↓

?KZΔSΔ↓ Station Height RW
!KZΔSΔΔ|ΔΔΔΔΔΔΔΔΔΔΔ0.0000ΔmΔΔΔΔ↓

?KLN1Δ↓ Request for Language R0
!KLN1ΔΔ|ΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔΔ↓
```

The following parameter Hz0 takes up a special position:

```
?KHZ0↓ the displayed Hz direction is
output in the selected format

!KHZΔΔΔ|ΔΔΔΔΔΔΔΔΔΔΔ0.00000ΔgonΔ↓ sets the Hz direction to
the preset value (here 0.00000
grad)
```

Designations:

```
RO parameter can only be read
RW parameter can be read and set
```

All parameters are output in the selected units, resolutions etc. Parameters can be entered irrespective of the parameters currently set. If call or setting commands include errors of syntax or content, the Trimble 3300DR R answers with 'E↓'.

Δ - blank

Trimble 3300DR controlled from Map500 or TSC1/TSCe

Trimble 3300DR and external controllers / dataloggers

Since Trimble 3300DR is the ideal sensor system only the user can control the Total Station from external units supplied by Trimble.

Map500 (Graphical Field Information System) and TSC1/TSCe are optimal controllers for doing Intergated Surveying with the system Trimble 3300DR.

Command and data exchange can be performed between and by

Trimble 3300DR Map500 cable

“Data transfer cable”

Order number: 7081779460000


or

between and by

Trimble 3300DR TSC1/TSCe cable

“Cable TSC1/e to Trimble 3300 / 3600”

Order number: 7081809001000



⚠ Attention!

First connect both units, with the recommended cable, start and prepare Trimble 3300DR for remote control and than start and configure Map500 or TSC1/TSCe!

Operation and settings of Trimble 3300DR

Trimble 3300DR and Map500 (V2.0)

Each instrument type of the series Trimble 3300DR (Trimble 3303DR, / 305DR / 3306DR) can be used to be remote controlled.

This is as well valid for the instruments with extended temperature range

Trimble 3303 x-treme and Trimble 3305 x-treme.

Start and setup Trimble 3300DR

Preparing the instrument for remote control

ON Press key

ON **MENU**

6 Setting Interface

YES to go to the menu

ESC to quit menu

↑ and

↓ to quit setting / to confirm change

MOD to change setting


ESC to quit menu

↑ and

↓ to quit setting / to confirm change

Switch ON the instrument.

Select the main menu.



Interface parameters



Interface parameters

Interface parameters for remote control:

Recording: V24/1

Data format: R4

Parity: even

Baud rate: 9600

Protocol: Xon/Xoff


Stop bits: 2 (not variable)

Data bits: 7 (not variable)

Operation and settings of Map500

Map 500 can be operated on any Field PC or on the PC in the office.

Start Map500 at Field PC or PC
Select icon „Map500“




Start screen Map500

Select „Setup Total Station“

via icon:
„Setup Total Station“


or

via pull down menu:
Miscellaneous → Instrument → Setup



Select type of instrument, interface parameters and instrument settings

Instrument: Trimble 3300DR
COM-port: COM1 – COM4
Setup status: DR mode
Laser pointer
for stationing: th= Theo ht: , ih= Staff ht:



Tip

Switch between DR mode and PR mode and switch ON / OFF the laser pointer can be applied from Map500.

Press button „Setup status“ in menu „Instrument Setup“.

These functions can also be applied at the Trimble 3300DR Total Station.



Switch between DR and PR mode



Switch Laser pointer ON / OFF

Operation and settings of Trimble 3300DR

Trimble 3300DR and TSC1 (V7.70) / TSCe (V10.0)

Each instrument type of the series Trimble 3300DR (Trimble 3303DR, / 305DR / 3306DR) can be used to be remote controlled. This is as well valid for the instruments with extended temperature range Trimble 3303 x-treme and Trimble 3305 x-treme.

Start and setup Trimble 3300DR

Preparing the instrument for remote control

ON Press key

ON **MENU**

Switch ON the instrument.

Select the main menu.

6 Setting Interface

YES to go to the menu

ESC to quit menu

↑ and

↓ to quit setting / to confirm change



MOD to change setting

ESC to quit menu

↑ and

↓ to quit setting / to confirm change

Interface parameters



Interface parameters

Interface parameters for remote control:

Recording: V24/1

Data format: M5

Parity: none

Baud rate: 9600

Protocol: Xon/Xoff or Rec500

Stop bits: 2 (not variable)

Data bits: 7 (not variable)

PC-Demo: OFF


4 Setting Instrument

YES to go to the menu

ESC to quit menu

↑ and

↓ to quit setting / to confirm change



MOD to change setting

ESC to quit menu

↑ and

↓ to quit setting / to confirm change

Angle measurement unit

10	Angle	DMS
↓ 11	Distance	m
12	Disp. Illum.	OFF
ESC	↑	↓
		MOD

Accuracy of displayed angle reading

1	Angle	1"
↓ 2	Distance	0.001m
3	U-Refer	zenith
ESC	↑	↓
		MOD

5 Dset

MOD to change setting

ESC to quit menu

↑ and

↓ to quit setting / to confirm change

EDM / distance measurement parameters

↑ 4	Setting Instr.		
5	Dset		
↓ 6	Setting Interface		
ESC	↑	↓	YES

Laser pointer

1	DR-Menu	NO
↑ 2	Long range	NO
3	L-Pntr	OFF
ESC	↑	↓
		MOD

Laser pointer OFF:

OFF

1 Input

YES to go to the menu

ESC to quit menu


↑ and

↓ to quit setting / to confirm change

Input PC, m, T, P



Input Prism constant



Use the same methodology for setting the Prism Constant to change the temperature and pressure settings.

⚠ Attention!

It is recommended that the prism constant is set in the Trimble 3300DR, not in the Trimble Survey Controller. However, if you choose to set the prism constant to zero in the Trimble 3300DR you should apply a prism constant in the TSC1/TSCe.

Furthermore it is recommended to set the scale to 1.000 and if a scale is to be applied, it is done in the TSC1/TSCe, using the coordinate settings available.

⚠ Attention!

Even though the correction values have been set in the 3300 Total Station, the information will not be passed to the TSC1/TSCe because the distances passed to the TSC1/TSCe already have the corrections applied.

Operation and settings of TSCe


⚠ Attention!

The screen shots are based on the Trimble Survey Controller TSCe. However, the same screens and settings can be followed though in the Trimble Survey Controller TSC1.

Start TSC1/TSCe


Select „Configuration“ from the main menu

Main menu



Configuration


Select „Survey styles“



Survey styles

Select function key „New“

Create Survey style Trimble 3300DR




Survey style Trimble 3300DR

Select „Survey“ style name and „Survey“ style type

Enter Survey new style name and style type

Enter to confirm settings /change and quit / enter next submenu




Style name e.g. Trimble 3300DR.
For style type choose „Conventional“.

Confirm / change settings in submenus, e.g. „Instrument“, „Target details“ and „Corrections“.

Select „Instrument“

Submenu „Instrument“




Selection setting „Instrument“

Submenu „Instrument“

Change / confirm settings of instrument

Enter to confirm settings /change and quit / return to higher level menu



Set manufacturer, model, interface parameters, update rate and precision of instrument.

Instrument parameters

Instrument parameters for remote control:


- Manufacturer: Trimble
- Model: Trimble 3300DR
- Baud rate: 9600
- Parity: none
- HA VA status rate: 2s / (1s)¹
- Instrument prec.: no setting needed

¹HA=Hz, VA=V

Submenu „Target details“

Change / confirm setting of target details

Enter to confirm settings /change and quit / return to higher level menu



Set prism constant and target height.

Attention!


Ensure that the prism constant is set to 0.0mm. Unless it has been set to 0.0mm in the Trimble 3300DR Total Station.

See also page 6-56!

Submenu „Target details“

Change / confirm setting of environmental factors
activate / deactivate corrections of earth curvature
and refraction

Enter to confirm
settings /change and quit /
return to higher level menu
(Trimble Survey style menu)



Set ppm, air pressure and temperature.

Corrections

Environmental corrections for remote control:

- PPM: 0
- Pressure: do not enter a value
- Temperature: do not enter a value
- Curvature and refraction: none

⚠ Attention!

Air pressure and temperature they have
already been applied by the Trimble 3300DR
total station.

See also page 6-56!

The Trimble 3300DR Total Station
automatically applies a earth curvature and
refraction coefficient.

OK (TSC1) or **Store** (TSCe) to confirm settings and quit / return to higher level menu

Accept the changes and close the Trimble 3300DR Survey style menu.

⚠ Attention!

Switch between DR mode and PR mode and switch ON / OFF the laser pointer can not be applied from the TSC1/ TSCe.

This has to be done at the Trimble 3300DR Total Station.



Switch between DR and PR mode



Switch Laser pointer ON / OFF

Recording data lines
See Data Formats

Mode	Rec. Mode	Content of Record	T1	T2	T3	Comments
Single meas.	1 2	P, C, I CCCC PPPPPPPPPPP CCCC PPPPPPPPPPP CCCC PPPPPPPPPPP CCCC PPPPPPPPPPP CCCC PPPPPPPPPPP CCCC PPPPPPPPPPP CCCC PPPPPPPPPPP CCCC PPPPPPPPPPP	T1 HD SD Y x n e n	T2 Hz Hz Hz x y e n Vk Hz	T3 Vk h/Z Vk h/Z h/Z h/Z h/Z I C SZ SZ	H/V mode, k=1,2,3,4 dep. on V syst. horizontal distance mode slope distance mode coordinates mode, sequence Y, X coordinates mode, sequence x, y coordinates mode, sequence n, e coordinates mode, sequence e, n k=1,2,3,4 depending on V system
Adjustment c/i	x	ADJUST	Vk	Vk	I	
	x	ADJUST	Hz	Hz	C	
	x	ADJUST			SZ	
Adjust. comp.	x	ADJUST			SZ	
Input values	x	INPUT	th	ih		
	x	INPUT	T ₋	P	A	
	x	INPUT	m			
	x	S	PPPPPPPPPPPP		Z	Z...station height
Compensator	x	COM-ON				compensator activated
	x	COM-OFF				compensator deactivated

Rec. mode:
1: MEM/1, V24/1
2: MEM/2, V24/2
3: 1+2

Mode	Rec. mode	Content of Record	T1	T2	T3	Comments
Unknown station	1	P, C, I				
	2	UN STAT				
	X	A	Y	X		reference point A, B, C, D, E
	X	A	SD	HZ	Vk	measurement to A, B, C, D, E
	X	A	VY	VX	Vz	residuals point A, B, C, D, E
Known station	X	S	Y	X		station coordinates
	X	S	m	Om	so	scale, orient., standard deviation
	X	KN STAT				
	X	S	Y	X		station coordinates
	X	A	Y	X		reference point A
Height stationing	X	A		HZ	Vk	measurement to A (Hz, V mode)
	X	A	SD	HZ	Vk	measurement to A (SD, Hz, V mode)
	X	A		Om		orientation (Hz, V)
	X	EL-STAT	m	Om		scale, orientation (SD, Hz, V)
	X	!				Height of A
Polar points	X	A	SD	HZ	Vk	Measurement to A
	X	S			Z	computed station height
	X	POLAR				
	X	CCCCPPPPPPPPPPPP	SD	HZ	Vk	original readings
	X	CCCCPPPPPPPPPPPP	Y	X	Z	coordinates
X	CCCCPPPPPPPPPPPP	T			Eccentricity Tv, Th, Tl, Tr, Ts	

Mode	Rec. mode	Content of Record	T1	T2	T3	Comments
Stake out	1	P, C, I				
	x	S-O				
	2	!	Y	X	Z	depending on stake-out-method
	x	!	PPPPPPPPPPPP	Y	X	depending on stake-out-method
	x	!	PPPPPPPPPPPP	Y	X	depending on stake-out-method
	x	!	PPPPPPPPPPPP	HD	HZ	depending on stake-out-method
	x	!	PPPPPPPPPPPP	HD	HZ	depending on stake-out-method
	x	!	PPPPPPPPPPPP	SD	HZ	reading for backsight point
	x		PPPPPPPPPPPP	dy	Dz	stake-out diff. dep. on meas. method
	x		PPPPPPPPPPPP	dy	Dz	stake-out diff. dep. on meas. method
	x		PPPPPPPPPPPP	dI	Dr	stake-out diff. dep. on meas. method
	x		PPPPPPPPPPPP	Y	Dz	stake-out diff. dep. on meas. method
	x		PPPPPPPPPPPP	Y	Z	verification
	x		PPPPPPPPPPPP	Y	X	verification measurement

Header									
For M5 Adr 00001 TI	START								
For M5 Adr 00002 TI		01	3305	102	900005	103	562		
For M5 Adr 00003 TI		04	30						
For M5 Adr 00004 TI		05	1	06	1				
For M5 Adr 00005 TI		20	1	21	11	22	16		
For M5 Adr 00006 TI		lh	1,900 m	lh	1,600 m				
For M5 Adr 00007 TI		l	0,0005 grd	lc	0,0025 grd	ISZ	0,0060 grd		
For M5 Adr 00008 TI	END	IT_	20 C	lP	1012 hPa	PC	0,035 m		
		l'm	1,000000						

Changed settings and adjustments

For M5 Adr.00009 TI INPUT	lth	2.000 m	lth	1.700 m	0.0055 grd
For M5 Adr.00010 TI ADJUST		92.4505 grd			-0.0010 grd
For M5 Adr.00011 TI ADJUST		284.1015 grd			0.0025 grd
For M5 Adr.00012 TI ADJUST					0.0055 grd
For M5 Adr.00013 TI ADJUST					-0.005 m
For M5 Adr.00014 TI INPUT		25 C			
For M5 Adr.00015 TI INPUT		1.000005			
For M5 Adr.00016 TI COM-OFF					
For M5 Adr.00017 TI COM-ON					
For M5 Adr.00018 TI HZ=0					
For M5 Adr.00019 TI HOLD					
For M5 Adr.00020 TI DR		0.000 m			0.000 m
For M5 Adr.00021 TI PR		2.000 m			0.030 m
For M5 Adr.00024 TI KN STAT					
For M5 Adr.00025 TI		1000.000 m			92.4435 grd
For M5 Adr.00026 PI1	S				0.000 m
For M5 Adr.00027 TI					

Introduction

An update is necessary if you load a new software version or if you want to change between the "Topo" and "Construction" software of the instrument.

Before starting the update, please save your data and use a fully charged accumulator battery.

The simplest way to get an update is via the Internet.


Homepage:

www.trimble.com

Trimble 3300DR  **PC**

Connect both devices by the serial interface cable and start the necessary update program.

Cable for data transfer

Trimble 3300DR  **PC**
with protocol Xon/Xoff:

Order number
708177-9470.000

Attention !

Different hardware versions require different update versions. Read all the instructions very careful.

In any case, please pay attention to the correct update - the correct instrument name when selecting the update files.

Once unpacked the files, the instrument type can no longer be concluded from them.

This update procedure describes the update of the former instruments Elta 40R, Elta 50R und Elta 50.

Doing the update with instruments younger generations please check the table below before:

Elta 40R → Elta R45 → Trimble 3303

Elta 50R → Elta R55 → Trimble 3305

Elta 50 → Elta R50 → Trimble 3306

Preparation on the Instrument



6 Setting Interface

YES to go to the menu

ESC to quit menu

↑ and

↓ to quit setting / to confirm change

MOD to change setting

ESC to quit menu

↑ and

↓ to quit setting / to confirm change

Select the main menu.



Interface parameters



Trimble 3300DR ↔ PC
Connect both devices by the serial interface cable and start the necessary update program.

Cable for data transfer
Trimble 3300DR ↔ PC with protocol Xon/Xoff:

Order number
708177-9470.000

Interface parameters for receiving update files:

- Baud rate: 4800
Protocol: Xon/Xoff
Parity: none
Stop bits: 1 (not variable)
Data bits: 8

8 Update/Service

YES to go to the menu
ESC to quit menu

↑ and

↓ to quit setting / to confirm change

⌂ to select / activate
Update
Service
EDM

ESC to quit menu




Menu Interface Trimble 3300DR



Tip

First configure the interfaces at the instrument and the PC. Then start the program "Update" at the instrument and afterwards run the software update at the PC.



The Update is carried out between _____ and _____ through

Trimble 3300 PC cable



This cable is also used for data transfer. The adapter included in the delivery allows the connection to 9 and 25 channel sockets.

Copy the contents of the diskette into a directory of your choice or start the software from the diskette (default).

Switch the instrument on and select the item Update.

Preparation on the PC

Please follow also the update instructions enclosed

Esc : to end the program

↑ ↓ : to select

↵ : to confirm selection

Configuration

Enter your data here. The configuration can be stored subsequently.




Esc : to end mask input

↵ : to end line input

Elta 40R


The question whether the Elta is in working order is to be answered in any case with YES.

↵ : to confirm



Please follow now exactly the instructions given on the screen.

↵ : to select the single steps



Trimble 3300DR display:

Update

YES to go to the menu

NO to start update




From now on, the PC software controls the instrument.

Update Elta 40R

Selection of the language desired (if available)


Esc : to end selection of language



Starting Update

Esc to start update


This operation takes some minutes comprising the transfer of one file with 30 and 4 files with 514 data records each.



The end of the update is acknowledged by clear acoustic signals. The instrument is switched off by software. The update has now been completed.

Update completed is flashing

↵ : to go to the start-up menu



Tip

If no connection is achieved, in all probability the wrong interface has been selected or there is an error in the reference.

Please pay also attention to a perfect cable connection.

The instrument adjustment defines all corrections and correction values for the Trimble 3300DR that are required to ensure optimum measuring accuracy.

Introduction	7-2
--------------	-----

V Index / Hz Collimation	7-4
--------------------------	-----

Compensator	7-6
-------------	-----

DR-EDM System – Laser Beam	7-7
----------------------------	-----


Introduction

Increased strain placed on the instrument by extreme measuring conditions, transportation, prolonged storage and major changes in temperature may lead to misalignment of the instrument and faulty measuring results. Such errors can be eliminated by instrument adjustment or by specific measuring methods.

Display page 2:

CHCK

to go to menu "Checking"



 Presettings
First steps

c/i

Additionally to activating and deactivating the compensator, this menu offers the following functions of checking and adjusting:

Determination of the vertical index correction (V index) and sighting axis correction (Hz collimation).

Comp

Determination of the compensator run centre.

⚠ Attention !

Before starting any adjustment, allow the instrument to adapt to the ambient temperature and make sure it is protected against heating up on one side (sun radiation).

i Vertical Index Correction

The vertical index error is the zero point error of the vertical circle with respect to the vertical shaft.

c Sighting axis correction


The sighting axis error is the deviation from the right angle between the trunnion axis and sighting axis.

k Trunnion axis correction

The trunnion axis error is the deviation from the right angle between the trunnion axis and vertical shaft (adjusted by the manufacturer).

Another instrument error considered is:

the compensator run centre error



V Index / Hz Collimation

The vertical index and sighting axis corrections should be recomputed after prolonged storage or transportation of the instrument, after major temperature changes and prior to precise height measurements.

These determinations are especially important due to the fact that the measurement is carried out only in the 1st telescope position in order to save time.

Tip

Before starting this procedure, precisely level the instrument using the level.

To determine the corrections, sight a clearly visible target in **Hz** and **V** from a distance of approx. 100 m. The sighting point should be close to the horizontal plane (in the range $V = 100^{\text{grads}} \pm 10^{\text{grads}}$). Start in the second face!

MEAS to start measurement in the 2nd telescope position

c=0 **i=0**


Setting of values
 $c = i = 0.$

MEAS to trigger measurement in the 1st telescope position



The current **c** and **i** values are displayed in the readings window.

c sighting axis correction **i**
 vertical index correction



new to confirm the new values /
to record

old to confirm the old values

```
old new
c 0.0025grd 0.0010grd
i -0.0010grd -0.0085grd
Rept old new
```

Display of results and recording

⚠ Attention !


During the computation of the vertical index and sighting axis correction, the program also determines the compensator run centre.

If either the **c** or **i** value exceeds the admissible range of ± 50 mgrads, the error message appears. The values are not saved, and the menu for new calculation is displayed again.

⚠ Attention !

If the values remain outside the tolerance range, despite accurate sighting and repeated measurement, you should have the instrument checked by the service team.

Compensator



The Trimble 3300DR features a compensator that compensates any vertical shaft inclinations remaining after instrument levelling in the sighting axis direction.

To check the compensator, its run centre should be determined at regular intervals and in particular prior to precise height measurements.


MEAS to start measurement in the 2nd telescope position



sz component in sighting axis direction

→ to turn Hz = 0

MEAS to trigger measurement in the 1st telescope position



ESC to quit the adjusting menu

Display of results and recording:



Attention !

For the accurate determination of the run centre, it is essential that the liquid in the compensator is allowed to settle, i.e. any vibration of the compensator must be avoided.


The DR EDM System

The red laser beam used for measuring without reflector is arranged coaxial with the line of sight of the telescope, and emerges from the objective port. If the instrument is well adjusted, the red laser beam will coincide with the visual line of sight. External influences such as shock or large temperature fluctuations can displace the red laser beam relative to the line of sight.

⚠ Attention !

Before starting adjustment, allow the instrument to adapt to the ambient temperature.

Inspection of the Laser Beam Direction



Check the system at regular intervals in order to avoid faulty measurements. A reflective target foil is provided. Set it up between 25 and 50 metres away facing the instrument. Move the telescope to face II. Switch on the red laser beam by activating the laser pointer function. Direct the instrument with the centre of the target plate and then inspect the position of the red laser spot with respect to the hair cross of the instrument. If the red laser spot lies outside the limits of the cross, the direction of the beam needs to be adjusted until it coincides with the hair cross.


⚠ Attention !

For adjustment use reflective foil only!


Tip

The direction of the beam should be inspected before precise measurement of distances is attempted, because an excessive deviation of the laser beam from the line of sight can result in imprecise distance measurements.

Adjusting the Laser Beam Direction



Pull the two rubber plugs out of the adjustment ports on the top of the telescope housing. To correct the vertical position of the laser spot, insert the alan key into the adjustment port 1 close to the front lens and turn the key clockwise to move the laser spot down. To correct position of the laser spot laterally, insert the alan key into the adjustment port 2 close to the diopter and turn it clockwise to move the laser spot left. Finally check the coincidence of laser spot and hair cross. Throughout the adjustment procedure, keep the telescope pointing to the reflective target foil.



Technical

At first the adjusting screws are of a high tension as they are self blocking. The screws will tighten automatically after the adjustment.

Attention !

After adjustment, replace the plugs in the adjustment ports to keep out humidity and dust.

The annex contains a compilation of symbols, keys, formulae, constants and error messages as well as explanations of concepts used for the Trimble 3300DR Routine Total Stations.

Furthermore, it gives an overview of the technical data and instructions for maintenance and care of the instrument.

Overview Softkeys 8-2

Overview Key Functions 8-6

Geodetic Glossary 8-7

Technical Data 8-14

Formulae and Constants 8-21

Error Messages 8-26

Maintenance and Care 8-29

Transport Case 8-30

Trimble 3303 / 3305 x-treme 8-31

HD		Setting the measuring mode: Measurement of reduced distances HD
xyh	yxh	Coordinate measurement, sequence X,Y,h Coordinate measurement, sequence Y,X,h
neh	enh	Coordinate measurement, sequence N,E Coordinate measurement, sequence E,N
SD	HzV	Measurement of slope distances SD Measurement of Hz direction and V angle
Hz=0		Setting the Hz direction to Hz=0
HOLD		Clamping the Hz direction for electronic circle orientation
END		Ending a function
th/ih		Input of reflector, instrument and station heights
th		Input of reflector height
ih/Zs		Input of instrument and station heights
→1	→2	Calling page 1 of the measurement menu Calling page 2 of the measurement menu
m	ft	Changing the distance unit: to meters/to feet entry of scale
gon	DMS	Changing the angle unit: to grads (gon) to DMS (degrees, minutes, seconds)
deg	mil	to decimal degrees to mils
V %		Display of the height angle in %
V ↙]		Display of the zenith angle (V=0 at the zenith)
V ↗]		Display of the vertical angle (V=0 at the horizon, $0 < V < 400$ grads)



Display of the height angle
($V=0$ at the horizon, $-100 < V < 100$ grads)



Setting the Hz counting direction to clockwise
Setting the Hz counting direction to anticlockwise
(only in display)



Calling the checking and adjustment menu



Terminating a function, quitting a submenu



Selecting the next upper line in the bar menu / in
the internal memory
Selecting the next lower line in the bar menu / in
the internal memory



Setting the cursor one character backward
Setting the cursor one character forward



Incrementing a value
Decrementing a value



Modification of the displayed value



Confirmation of an entry



Acceptance of an option
Rejection of an option



Calling the function for the determination of the
collimation and vertical index correction



Calling the function for the determination of the
compensator run centre correction



Activating the compensator
Deactivating the compensator



Retaining the old value
Entering the new value



Repeating the process



Setting the vertical index correction to $i=0$



Setting the collimation correction to $c=0$

A	B	C	D	Activating the reference point A, B, C, D
P				Activating the new point P
A=S	B=S	C=S		Using the station coordinates as reference point coordinates
P=S				Using the station coordinates as the coordinates of the new point
A=P				Using P as the new reference point A (connecting distance)
y	x	e		Input of a distance/offset (in the Vertical Plane program)
hSet				Setting the reference height (in the Vertical Plane program)
ZSet				Setting the reference height Z (in the Object Height program)
xSet	ySet	nSet		Setting the reference direction: (in the Vertical Plane program) (in the Vertical Plane program) (in the Vertical Plane program)
A-P	P-P			Referring the connecting distance to: the reference point A the last point used
Inp				Input of a value
m				Calling the scale entry (in the Coordinates programs)
YX	XY			Setting out according to nominal coordinates without height or entry in MEM
EN	NE			
YXZ	XYZ			Setting out according to nominal coordinates with height or entry in MEM
ENZ	NEZ			

HD	HDh	Stake out using known stake out elements without with height	
Z		Input of a height in the internal MEM memory	
Z-j	Z-n	Changing to setting out: with height without height	
Test		Calling the measurement of the setting out points	
S-O		Calling the stake out of the next point	
Stat		Starting stationing in elevation	
S		Input of station coordinates for Unknown Station	
Inp		Input of scale for planimetric stationing	
Hz		Input of Hz for Known Station	
Disp	Del	Edt	Display of data lines of the memory Deletion of data lines of the memory Changing the point number and point code of a data line
?	?P	?C	Search for: data lines in the memory a point number in the memory a point code in the memory
?A			Search for an address in the memory
? ↓			Continue search according to the same criterion
all			Selecting all data lines of the memory
Ecc			Calling the program measure inaccessible points
INT			Calling support programs for DR mode, calling program Intersection of vertical planes.

MEAS

First function
Starting a single measurement or Tracking mode

ON

First function
Switching the instrument on

ON **OFF**

Second function
Switching the instrument off

ON **DR**

Second function
Switch between DR and PR measure mode

ON **EDIT**

Second function
Calling the memory

ON **PNo**

Second function
Calling the input of point number and code

ON **MENU**

Second function
Going to the main menu

ON ✱—

Second function
Switch Laser pointer ON / OFF

A

Addition constant	Addition value for distance measurement, default 0.
Addition correction	Correction of the addition value ("addition constant") of the distance measuring instrument, e.g. if using prisms of other manufacturers.
Alignment	Application program for the determination of any number of points on the straight line AB.

B

Backsight point BP	A point with known coordinates used for the station point determination and/or for <i>orientation</i> .
Bearing angle	H _z bearing orientated to a reference bearing (generally to grid north).
Bearing (H _z)	Value read in the horizontal circle of the instrument, whose accidental orientation is determined by the zero position of the graduated circle.

C

Calibration scale	Influences systematically the distance measurement. Best possible adjustment to 1.0 by the manufacturer. Without influence on all other scale specifications.
Code, code number	Reference number for the point description, characterises certain point types.
Compensation	Automatic mathematical consideration of the <i>vertical axis inclinations</i> measured with the <i>compensator</i> in the sighting direction, in V angle measurements.
Compensator	Used to determine the current vertical axis inclination in the sighting axis direction, can be deactivated and activated again, as required; a graphical symbol in the information menu displays the activated compensator.

Compensator run centre	Electronic centre of the clinometer in sighting axis direction.
Connecting distance	Spatial distance, plane distance and height difference between 2 target points.
Control point	Point for checking the <i>orientation</i> of the instrument. It is defined at the beginning of a measurement and can be measured at any time for checking.
Coordinates	Measuring program for the determination of points in a higher-order coordinate system.
D	
Default	Standard value for an instrument setting.
Direct reflex mode	Distance Measurement mode without prism or reflective foil.
Distance measuring mode	Depending on the purpose of application, the distance measurement is to be selected by pressing the MEAS key in the normal mode or the continuous distance measurement (tracking) is to be selected by pressing the MEAS key twice.
E	
Error limits	Limit values which can be set by the user for certain readings or results.
Eccentricity	Support program to measure inaccessible points.
F	
G	
H	
Hardkeys	See key functions.
Height stationing	The height of the station point is derived from measurements to known height points.
Hz circle orientation	A predefined horizontal bearing value is allocated to the sighting direction to a measurement point.

Hz collimation correction	(also called collimation or sighting axis correction) Correction of the deviation of the sighting axis from its required position right-angled to the trunnion axis. Determination by measurement in two positions, automatic correction in the case of measurements in one position. I
Incrementing	(increment=interval) Automatic counting of the point number (increase by 1) after the measurement.
Instrument height	Height of the telescope trunnion axis above the station height (ground point).
Interface	Contact point between 2 systems or system areas, in which information is interchanged according to defined rules.
Intersection	Support programs for DR mode, Program Intersection of vertical planes.
	K
Key functions	First and second functions; for switching the instrument on, starting the measurement, switching off, illuminating the display, calling the memory, entering PI and going to the main menu, starting of tracking.
	L
Levelling	Vertical adjustment of the vertical axis of the instrument; the levels of the instrument are centred by turning the tribrach screws. The levelling can be checked by means of the digital display of inclinations after pressing the softkey CHCK .
Long Range mode	Extended distance measurement mode to prisms and reflective foil.

M

Measuring mode

In the measurement menu, the following measuring modes can be selected:

- HzV display in the theodolite mode
- HD display of reduced distance and height difference
- yxh local rectangular coordinates
- SD display of the original readings

O

Object height

Determination of the height of points to which a direct distance measurement is impossible, by means of an angle measurement.

Orientation

When orientating the instrument, the *bearing angle* of the zero of the graduated circle Omega (Om) is calculated. For this purpose, measurements to a *backsight point* can be made or the *bearing angle* of a known point can be entered.

Orthogonal lines

Application program to check lines for orthogonality, setting out right angles and especially for measurements in the case of visual obstacles.

P

Parallel lines

Application program to check the parallelism of straight lines or for setting out parallels with only one point given.

Point identification

Identification of the measured point by a maximum of 12 characters for the point number and up to 5 for the point code.

Point number/Point code

Part of the point identification.

Station + Offset

Application program for the determination of rectangular coordinates of any point in relation to a straight line defined by the points A and B.

Polar/Detail Point determination

Determination of the coordinates and height of new points by distance and bearing measurement.

Q

R

Recording mode	Selectable in the menu Interface/Recording: Off no recording MEM/1 Recording of measured data sets in MEM (not for Trimble 3306DR) MEM/2 Recording of computed data sets in MEM (not for Trimble 3306DR) MEM/3 Recording of all data sets in MEM (not for Trimble 3306DR) V24/1 Recording of measured data sets through V24 V24/2 Recording of computed data sets through V24 V24/3 Recording of all data sets through V24
Record current settings	Recording of Header and changed settings of instrument
Reference point	Used here as reflector station for the indirect height determination.
Reflector height	Height of the reflector (prism centre) above its station (ground point).
Refraction coefficient	Measure for the light-beam refraction in the atmosphere; can be set by the user.
Run centre	See <i>Compensator run centre</i> .
S	
Scale	With a <i>scale</i> , the measured distance is varied proportionally to the length and can thus be adapted to certain marginal conditions. There exist a series of direct and indirect scale effects: <i>calibration scale, projection reduction, height reduction, reticle scale</i> .
Softkey	Function key which has several functions in dependence on the program.

Standard measurement menu	The determination of points takes place within the local measuring system. The station of the instrument with the coordinates (0,0,0) represents the zero point of this system of coordinates. The <i>orientation</i> is determined by the zero direction of the Hz circle. The data are fitted in a given system of coordinates (Trimble 3306DR) only during the further processing (possibly in the office) or a stationing is carried out in order to measure in a given system of coordinates.
Standard settings	Values set by the manufacturer for all configuration parameters.
Stake out	Program to stake out or search points.
Stationing	Precedes any determination of points in a defined system of coordinates. Consists in the station point determination and/or calculation of the orientation of the graduated circle: Stationing on a known or unknown point (free stationing), height stationing (height only).
Stationing on a known point	Given: Station point coordinates / backsight bearing. The <i>scale</i> and the <i>orientation</i> of the graduated circle are derived from the measurements to known <i>backsight points</i> .
T	
Tracking	Continuous measurement of angles and distances. Hz and V values are constantly measured and displayed. Set permanent measurement for distance measurements.
V	
Vertical axis inclination	The inclinations of the vertical axis of the instrument in sighting axis direction are measured with the <i>compensator</i> , indicated digitally and can be requested on the display.

Vertical plane

Application program for the determination of points in a vertical plane by means of an angle measurement.

W

Z

Trimble 3303DR

**Trimble 3305DR
Trimble 3306DR**

Angle measurement

Accuracy as per DIN 18723	1.0 mgrad (3")	1.5 mgrads (5")
---------------------------	-----------------	------------------

Angle measurement

Hz and V circles	electronic absolute,	
Measuring units	360° (DMS, DEG), 400 grads, 6400 mils	
Vertical reference systems	zenith, height and vertical angle, slope in percent	
Least display unit (selectable)	1''/2''/10''	
	0.0005°/0.002°/0.005°	0.0005°/0.001°/0.005°
	0.2 / 1 / 5 mgrads	0.5 / 1 / 5 mgrads
	0.01/0.1/0.5°	

Telescope

Magnification	26 x
Aperture	40 mm
Length	193 mm
Field of view at 100 m	2.9 m
Shortest sighting	1.5 m
Special features	variable reticle illumination

Trimble 3303DR**Trimble 3305DR****Trimble 3306DR****Distance measurement**

Method (DR mode)	electro-optical, modulated red laser light 660nm /< 1 mW (internal: red laser diode 660nm/<1,1mW)
Transmitter/Receiver optics	coaxial, in telescope
Beam divergence	0,4 mrad / 1,5 mrad
Resolution	0,1mm
Measuring units	alternate display of results in m/ft

Distance measurement time

Standard	2.0 s
Tracking	1.2 s

Prism mode

Standard	3 s up to 30m + 1 s / 10m
Tracking	1,6 s

Direct reflex mode**Distance measurement**

Accuracy as per DIN 18723		2mm+2ppm
Prism	Standard	5mm+2ppm
	Tracking	3mm+2ppm
Reflex Foil	Standard	5mm+2ppm
	Tracking	3mm+2ppm
Direct Reflex	Standard	10mm+2ppm
	Tracking	

Distance measurement

Range ¹	Standard range
with 1 prism	1,5m - 3000m
with 3 prisms	1,5m - 5000
with reflective foil 20x20mm	2,5m – 100m
with reflective foil 60x60mm	2,5m – 250m

with 1 prism	1000m – 5000m
with 3 prisms	1000m – 7500m
with Reflex Foil 20x20mm	2,5m – 200m
with Reflex Foil 60x60mm	2,5m – 800m

Direct reflex measurement² 70m(Kodak Gray,18%) / 100m(Kodak Gray,90%)

Trimble 3303DR**Trimble 3305DR
Trimble 3306DR****Levelling**

Circular level	10'/2 mm
Tubular level	30"/2 mm

Compensator

Type	uniaxial compensator
Working range	5'/100 mgrads
Accuracy	1,5"

Clamps and tangent screws

coaxial, parallel axes

Optical plummet

Magnification	2 x
Shortest sighting distance	0.5 m

Display screen

4 lines with 21 characters each,
graphic capabilities (128 x 32 pixels)
display illumination, variable contrast setting

Keyboard

7 keys, display oriented, variable key functions

Measuring menu

Hz-V/SD-Hz-V/HD-Hz-h/y-x-h
setting, input, adjustment

**Application programs
(supported by graphics)**

Connecting Distances, Object Height + Width,
Station + Offset, Vertical Plane, Area Calculation,
Stake out Point to Line
(orthogonal lines, parallel lines, alignment)

Trimble 3303DR**Trimble 3305DR
Trimble 3306DR****Coordinates programs
(supported by graphics)**

Unknown Station, Known Station,
Stationing in elevation,
Polar/Detail Points, Stake Out

Recording

internal data memory³
(approx. 1900 data lines)

externally via RS 232 C/V24 interface
switchover in the menu interface/recording,
slip ring on stationary base

Power supply

NiMH battery pack 6 V/1.3 Ah;
sufficient for approx. 1000 angle and
distance measurements

Operating temperatures

-20°C to +50°C

Dimensions

Instrument (WxHxD)	173 x 268 x 193 mm
Trunnion axis height with DIN centring spigot/ Trimble 3-PIN centring	175 mm 196 mm

Weights

Instrument incl. battery and tribrach	3.5 kg
Case	2.5 kg

¹ Standard clear: No haze, overcast or moderate
sunlight with very light heat shimmer. Range and
accuracy are dependent on atmospheric
conditions and background radiation.

² typically

³Not available for Trimble 3306DR.

Electromagnetic Compatibility (EMV)

Die EU Conformity Declaration confirms the perfect function of the instrument in an electromagnetic environment.

⚠ Attention !

Computers connected to the rimble 3300DR which are not part of the Trimble System delivery, have to meet the same EMV requirements in order to ensure that the overall configuration complies with the applicable interference suppression standards.

Interference suppression as per:
EN 55011 class B

Noise immunity:
EN 50082-2

🔑 Tip

Strong magnetic fields generated by mid and low voltage transformer stations possibly exceed the check criteria. Make a plausibility check of the results when measuring on such conditions.

Single battery Charger



⚠ Attention !

Make sure that the input voltage switch reading matches the mains voltage at your location!

If you connect the charger to 230V when the voltage selector shows 115V an internal fuse will blow.

If you connect the charger to 115V and it is set for 230V the red charge led flashes.

General

This single battery charger is designed for NiCd and NiMH batteries, 5 or 10 cells. Die NiMH Battery of the Trimble 3300DR (6V 1,3 Ah [7025049040000](#)) has 5 cells. The charger changes the charging parameters depending on a code resistor in the battery.

A micro controller measures the code resistor and the NTC resistor in the battery and changes the maximum voltage and charging time accordingly. It uses the peek voltage method to indicate when the battery is almost fully charged.

To complete the charging it applies a constant top charging current of 100 mA until the maximum charging time timer has run out. Thereafter a pulsating trickle charging current will be applied to the battery as long as it is connected to the charger.

To prevent damage to the battery the charger has the following safety functions:

- A maximum charging time timer
- Max and min temperature stop, if the battery becomes too hot or cold. This function requires a NTC resistor in the battery
- Battery over and under voltage detection

Low battery voltage

If the battery voltage is lower than about 3V (the **Error** LED is turned on) the charger starts the charging with 100 mA current until the voltage increases over 3V. Then normal charging starts. Sometimes battery voltage increases rapidly first and then falls slowly for some time. If this goes on for more than 10 min the charger may interpret this as the battery is already fully charged. The charger stops and has to be restarted.

High battery temperature

The battery is equipped with an NTC resistor. The charger monitors the battery temperature with this resistor and stops if the temperature rises above 45 degrees Celsius and the **Error** LED will be turned on. The reason for this may be high ambient temperature or the charger has failed to stop charging and the battery temperature rises due to a fully charged condition.

Technical Data

Charged battery

It is not recommended to restart a charging cycle when the charger has indicated 100%. The charger waits about 10 minutes before it senses the battery condition and repeated restarts can cause a heavy overcharge and damage to the battery.

Worn out batteries

Old and well-used battery has a higher voltage when charged. If the voltage becomes to high a protection mechanism stops the charging and error will be indicated.

Continues connection to charger

A battery should not be connected to the charger for a prolonged time.

Disconnect the charger from main supply if it not will be used for a long time.

Technical Data

INPUT

	Nominal	Comments
Voltage	~115 Vac; 50/60 Hz	90V to 127V
	~230 Vac; 50/60 Hz	190V to 250V
Power	20 W	

OUTPUT

Reverse polarity protection	Max 30 V	
-----------------------------	----------	--

CONTROL

High temperature stop	45 °C	The charger must be restarted to continue charging
Low temperature stop		The charger begins charging when temperature becomes higher then 0 °C

Charging the battery

Safety Notes

⚠ Attention !

Only charge rechargeable Nickel Metal Hydride (NiMH) and Nickel Cadmium (NiCd) chemistry battery packs. Attempts to charge other types of battery may results in explosions.

LED indicator



No bat.	No battery connected
Error	Error see text
Charge	Fast charging
100%	Battery charged

Connect the appropriate power supply cable to the charger and insert it in the power outlet The yellow **No Bat** led will be turned on.

Chose an appropriate battery cable and insert it at the charger's battery connector. Finally connect the cable to the battery. The yellow **No bat** led will now be turned off and the red **Charge** led will be turned on. The charging process has now started and will continue until the charger detects a fully charged battery and the green **100%** led turns on.

The charging time for the DiNi – Battery is approximately 2 hours and 30 minutes. The charger will time out in 4 hours and 15 minutes.

Computational Formulae for Angle Measurements

V angle measurement

$$V_k = V_o + i + SZ_a$$

V_o = uncorrected V circle reading

i = index correction

SZ_a = current vertical axis inclination in the sighting direction

Hz bearing measurement

$$Hz_k = Hz_o + Hz_1 + A$$

Hz_o = uncorrected Hz circle reading

$Hz_1 = c/\sin(I/k)$ - collimation correction

A = circle adjustment for orientation

Computational Formulae for Distance Measurements

$$D_k = D_o \cdot M_i + A$$

D_k = corrected distance

D_o = uncorrected distance

A = addition constant

M_i = influence of meteorological data

Influence of meteorological data:

$$M_i = (1 + (n_o - n) 10^{-6}) \cdot (1 + (a \cdot T \cdot T) 10^{-6})$$

n = current refractive index

$$= (79.146 \cdot P) / (272.479 + T)$$

n_o = reference refractive index = 255

P = air pressure in hPa or torr or in Hg

T = temperature in degrees C or degrees F

a = coefficient of vapour pressure correction
= 0.001

carrier wavelength

0.86 microns

modulation wavelength

20 m

precision scale

10 m

Reduction Formulae

Slope distance SD

Distance between the instrument's trunnion axis and the prism. It is computed from the measured slope distance and the entered scale:

$$SD = D_k \cdot M$$

SD = displayed slope distance

D_k = basic distance

M = scale

Horizontal distance HD

$$HD = (E_1 + E_2) \cdot M$$

HD = displayed horizontal distance

$$E_1 = D_k \cdot \sin(Z + R)$$

R = influence of refraction

$$= 6.5 \cdot 10^{-7} \cdot D_k \cdot \sin(Z)$$

E_2 = influence of earth curvature

$$= -1.57 \cdot 10^{-7} \cdot dh \cdot D_k \cdot \sin(Z)$$

D_k = corrected slope distance

Z = measured zenith angle [grads]

M = scale

Difference in elevation h

$$h = dh_1 + dh_2$$

h = displayed difference in elevation

$$dh_1 = D_k \cdot \cos(Z)$$

$$dh_2 = (D_k \cdot \sin(Z)) \cdot (D_k \cdot \sin(Z)) \cdot 6.8 \cdot 10^{-8}$$

= influence of earth curvature and refraction
(k = 0.13)

Distance reduction to MSL

Distances measured at elevation Z can be reduced to MSL by computing the following scale outside the instrument (computation formula applies to all earth radii):

$$m = R / R + Z$$

$$S_2 = S_1 \cdot m$$

R = earth radius (6370 Km)

Z = elevation above MSL (Km)

S₁ = measured distance at elevation Z

S₂ = reduced distance at MSL

If this scale is entered into the Trimble 3300DR, the computed distances are reduced directly in the instrument.

Verifying on Calibration Distances

Basically, all measured distances are corrected with reference to:
the entered scale,
the entered addition constant,
the influence of pressure and temperature,
internal influencing variables.

⚠ Attention!

Prior to the practical realisation of the calibration measurement, the current values of the parameters scale, addition constant, pressure and temperature are to be entered. The scale is to be set to default: 1.000000. This is to secure that all corrections are made completely and perfectly. Furthermore, this allows a direct comparison of nominal and actual values in the case of given distances.

If a weather correction is to be carried out externally, the temperature must be set to 20°C and the air pressure to 944 hPa. Then, the internal correction goes to zero.

Prism and Addition Constants

All Trimble Total Stations of the former Zeiss Elta series, in combination with their reflectors are adjusted with the **addition constant 0.000**.

In case of measurements to reflectors of other manufacturers, a possibly existing addition constant can be determined.

Another possibility consists in calculating an addition constant by means of the known prism constant of the reflector used. This prism constant is calculated as function of the geometric value of the prism, the type of glass and the place of the mechanical reference point. The prism constant for former Zeiss reflectors determined that way is **-35 mm**.

Relation between the addition constant A_{CZ} for former Zeiss instruments, the prism constant P_{CZ} for former Zeiss reflectors and the prism constant P_f for other manufacturers reflectors:

$$A_{CZ} = P_f - P_{CZ}$$

Example:

Zeiss reflector	prism constant
P_{CZ}	= -35 mm

Foreign reflector	prism constant
P_f	= -30 mm

Addition constant for former Zeiss Elta instruments in connection with this foreign reflector $A_{CZ} = + 5 \text{ mm}$

In this case, in the Trimble 3300DR the addition constant is computed: + 0.005 m.

Error Message**What to do?**

001	ROM error
002	RAM error
003	Data EEPROM was initialised
005	Data EEPROM error

It is not advisable to continue the measurement as all basic settings of the instrument may have been changed.

040	Error in
059	dist. measuring unit

If this error occurs repeatedly, please inform the service.

042 – Ambiguity¹

201	No Compensator
202	Compensator oper. range exceeded
203	No Compensator-Value
204	No Angle Sensor
205	No Initialisation Angle Sensor
206	No Angle Value

Time Out in contact with the Compensator
Call the service

Compensator range of 5' exceeded

No measurement possible – instrument
inclination to big

Time Out in contact with the angle sensor
Call the service

No Initialisation of the angle sensor
Call the service

No angle measurement possible, to fast
movement in angle tracking
The digits are replaced by dashes

207	Data-EEPROM Error in writing
208	Data-EEPROM Error in writing
209	Data-EEPROM Error in reading
210	Daten-EEPROM Error in reading

Error in reading or writing EEPROM of the angle
sensor or compensator

It is possible that there are changed important
settings

Call the service

211	Error Communication
212	Error Communication

Error in communication with the angle sensor or compensator, call the service

410	MEM not initialised!
------------	----------------------

Initialisation can only be performed by service staff

411/	Defect in system area
412	

Work with the data memory is not possible, call the service

413	Defect in system area, reading is possible
415	MEM reading error
416	MEM writing error

In the event of error messages 413...416, try to save the content of the data memory by transmission to the PC. If the error occurs again when recording is repeated, call the service.

417	MEM is full
------------	-------------

Read out the memory content, delete the memory.

418	Pointcode or Point-number not found
419	

Correct the entry.

581	Transmission error (in data transmission)
584	Transmission time out (in XON/XOFF protocol)
586	Transmission time out (in XON/XOFF Rec 500 protocol)
587	I/O time out, Rec 500 protocol
588	REC 500 protocol error

If the general recording errors 518...588 occur, first try to repeat recording. If the error occurs again, check the interface parameters, the cable and the recording program at the other end.

¹ Warning could appear while target is moving during measurement or doing measurement at distances longer than 300m and shorter than 1,5m in DR mode to prisms or high reflective surfaces.

Tip

If the warning "inadequate geometrical conditions" is ignored in the application programs, the last digit of the displayed values is replaced by 3 dots.

If a recording error occurs, the last data line has usually not been transmitted.

Before you call the service

Before you contact the service please notice the following service menu information. This information is very important to analyse the instrument errors.


ON MENU

Update/Service

YES Go to Menu




Service



Instructions for Maintenance and Care

Instrument	<p>Allow sufficient time for the instrument to adjust to the ambient temperature.</p> <p>Use a soft cloth to remove dirt and dust from the instrument.</p> <p>When working in wet weather or rain, cover the instrument during longer breaks with the protective hood.</p>
Object lens and eyepiece	<p>Clean the optics with special care using a clean and soft cloth, cotton wool or a soft brush, do not use any liquid except pure alcohol.</p> <p>Do not touch the optical surface with the fingers.</p>
Prisms	<p>Steamed prisms must have sufficient time to adjust to the ambient temperature. Remove afterwards the moisture using a clean and soft cloth.</p>
Transportation	<p>For transportation over long distances, the instrument should be stored in its case.</p> <p>When working in wet weather, wipe the instrument and case dry in the field and let it dry completely indoors, with the case open.</p> <p>If, for the purpose of changing the station, the instrument with the tripod is transported on the shoulder, please make sure that instrument and person will not be damaged or injured.</p>
Storage	<p>Let wet instruments and accessories dry before packing them up.</p> <p>After a long storage, check the adjustment of the instrument prior to use.</p> <p>Observe the boundary values for the temperature of storing, especially in the summer (interior of the vehicle).</p>

Keeping the Measurement System in the Case



- 1 Protective hood
- 2 Adjusting tools:
Pin for adjusting the optical plummet,
Pin for adjusting the clamping power of the tripod legs
- 3 Instrument
- 4 Battery
- 5 Plumb line
- 6 Operating instructions

Fig. 1: Instrument case

Trimble 3303 / 3305 xtreme**Extended Temperature Range**

For surveying in extreme climatic conditions, a special version of the instrument series Trimble 3300 suitable for an extended temperature range to -35° is available, broadening the operative range of the Routine Total Stations considerably as far as seasons and geographical features are concerned.

Due to the heated display, the instrument works just as in the normal temperature range. The required heating energy is provided by the external battery.

For operation in low temperatures run the instrument from the external battery.

The instrument is automatic power from the external battery after connecting to the instrument. Disconnecting the external battery the instrument does switch over automatically to the internal battery.

The heating switches on automatically at about -10°C . if the instrument is connected with the external battery.

The external battery provides energy for about 8 hours at -35°C .



Trimble Engineering and Construction Division
5475 Kellenburger Road
Dayton, Ohio 45424
U.S.A.

800-538-7800 (Toll Free in U.S.A.)
+ 1-937-233-8921 Phone
+ 1-937-233-9004 Fax

www.trimble.com